

# Customizing z Systems Development and Test Environment for z/OS ADCD July 2016 Edition



---

# Contents

## Customizing the July 2016 Edition z/OS 2.2 ADCD for z Systems Development and Test Environment. . . . . 1

|   |    |
|---|----|
| Defining the device map for z/OS 2.2 ADCD . . . . .                       | 1  |
| Sample program to create device map . . . . .                             | 3  |
| Starting and stopping the z/OS 2.2 ADCD . . . . .                         | 4  |
| Start the z Systems Development and Test<br>Environment . . . . .         | 4  |
| Stopping the z Systems Development and Test<br>Environment . . . . .      | 5  |
| Configuring a working z/OS system . . . . .                               | 6  |
| A brief introduction to z/OS system configuration                         | 6  |
| Configuration overview. . . . .   | 8  |
| Logging on to TSO . . . . .   | 8  |
| Creating new zFS files for /tmp and /u. . . . .                           | 8  |
| Setting up TCP/IP . . . . .   | 11 |
| Optional tasks . . . . .  | 16 |
| z/OS 2.2 ADCD for z Systems Development and<br>Test Environment . . . . . | 20 |
| Customization help and location of product<br>PGMDIRs . . . . .           | 20 |
| What's new in this release . . . . .                                      | 20 |
| Products contained in this release . . . . .                              | 21 |
| Reported problems, fixes, and maintenance. . . . .                        | 37 |

|  |    |
|--|----|
| Build structure . . . . .  | 37 |
| Migration Guidelines . . . . .                                   | 40 |
| LOADPARMS Options . . . . .                                      | 41 |
| Console PF Key Settings . . . . .                                | 42 |
| USERIDS . . . . .  | 43 |
| Maintenance Service Levels . . . . .                             | 43 |
| Hints and tips to manage the z/OS 2.2 ADCD. . . . .              | 43 |
| Page data sets . . . . .   | 43 |
| Starting IMS and running an IVP transaction . . . . .            | 44 |
| WLM configuration provided on ADCD z/OS. . . . .                 | 44 |
| ACS routines provided on ADCD . . . . .                          | 45 |
| Recreating the coupling data sets . . . . .                      | 45 |
| Allocating DB2 archive logs into an esoteric<br>device . . . . . | 45 |
| Steps for dumping SMF data into GDG data sets                    | 53 |
| Using the esoteric devices . . . . .                             | 53 |
| Starting IBM Health Checker for z/OS . . . . .                   | 53 |
| Starting IBM z/OS Management Facility<br>(z/OSMF). . . . .       | 53 |
| Starting WebSphere Application Server (WAS V8)                   | 54 |
| Starting WebSphere Application Server (WAS<br>V8.5) . . . . .    | 57 |

## Index . . . . . 61



---

# Customizing the July 2016 Edition z/OS 2.2 ADCD for z Systems Development and Test Environment

Learn how to customize the z/OS® 2.2 Application Developers Controlled Distribution for IBM® z Systems™ Development and Test Environment July 2016 edition.

This z/OS 2.2 distribution is a unique distribution that was created specifically for sites that are entitled to IBM z Systems Development and Test Environment, based on the Application Developers Controlled Distribution (ADCD). It is referred to in this IBM Knowledge Center as the z/OS 2.2 ADCD. It contains many of the products and subsystems you expect in a z/OS system. Most of these products and subsystems run without any customization, and some need some customization or initialization to make them work. These customizations are centered on changes that are needed to establish TCP/IP connectivity and update the infrastructure to allow z/OS 2.2 to properly run on IBM z Systems Development and Test Environment.

**Restriction:** Any z/OS ADCD for z Systems Development and Test Environment, and any related software, are supplied as a convenience. IBM does not support the operating system distributions that are made available with z Systems Development and Test Environment. You can apply fixes to any z/OS distribution through normal SMP/E facilities.

Before customizing this z/OS 2.2 ADCD, you must first install IBM z Systems Development and Test Environment, and download and install the z/OS 2.2 ADCD. For instructions, see Installing July 2016 Edition z/OS 2.2 ADCD for z Systems Development and Test Environment. Then, to customize the z/OS 2.2 ADCD distribution, do the steps that are described in the next three topics. The last two topics contain reference information about the z/OS 2.2 ADCD distribution.

---

## Defining the device map for z/OS 2.2 ADCD

The IBM z Systems Development and Test Environment allows the customization of the z Systems resources available within the virtualized environment. The resources can be defined in a device map or *devmap*.

The sections and syntax of device maps are explained in detail in the "1090 Control Files" section of the zPDT Guide and Reference.

The system volumes that represent the z/OS distribution are defined in an *awsckd* stanza, and are mounted at arbitrarily chosen addresses within the range of valid addresses that are defined by the z/OS distribution's IODF. Historically in a z/OS ADCD, the *xxRES1* and *xxSYS1* volumes are mounted at the same addresses that are documented in the zPDT Guide and Reference, and address 0AA3 is always reserved for volume *xxDBAR*.

The following examples, when combined, define a working device map with this z/OS ADCD for IBM z Systems Development and Test Environment. If you are using the coupling facility or Rational® Tokens, see Enabling the coupling facility and Setting up Rational Tokens.

```
[system]
memory 4096m
processors 3
3270port 3270          # port number for non-SNA (coax) 3270

[manager]
name aws3274 0001      # define non-SNA (coax) 3270 terminals
device 0700 3279 3274 mstcon
device 0701 3279 3274 tsol
```

For the network adapter definitions, the following example was added. One OSA is defined for connectivity to the host Linux system, called a “tunnel” OSA, and one is defined for establishing remote connectivity by using an ethernet adapter on the Linux host computer. Your setup might differ. For more information about configuring OSAs, see “Configuring a working z/OS system” on page 6 and the sections on connectivity in the zPDT Guide and Reference.

```
[manager]          # define network adapter (OSA) for communication with Linux
name awsosa 0024 --path=A0 --pathtype=OSD --tunnel_intf=y # QDIO mode
device 400 osa osa
device 401 osa osa
device 402 osa osa

[manager]          # define network adapter (OSA) for communication with network
name awsosa 22 --path=F0 --pathtype=OSD # QDIO mode
device 404 osa osa
device 405 osa osa
device 406 osa osa
```

Since the volumes are in the /home/ibmsys1/z1090/disks/ directory, the DASD definitions might look like the following example:

```
[manager]
name awsckd 0002
device 0A80 3390 3390 /home/ibmsys1/z1090/disks/B2RES1
device 0A81 3390 3390 /home/ibmsys1/z1090/disks/B2BLZ1
device 0A82 3390 3390 /home/ibmsys1/z1090/disks/B2SYS1
device 0A83 3390 3390 /home/ibmsys1/z1090/disks/B2CFG1
device 0A84 3390 3390 /home/ibmsys1/z1090/disks/B2C511
device 0A85 3390 3390 /home/ibmsys1/z1090/disks/B2C521
device 0A86 3390 3390 /home/ibmsys1/z1090/disks/B2C531
device 0A87 3390 3390 /home/ibmsys1/z1090/disks/B2DBA2
device 0A88 3390 3390 /home/ibmsys1/z1090/disks/B2DBA1
device 0A89 3390 3390 /home/ibmsys1/z1090/disks/B2DBB1
device 0A8A 3390 3390 /home/ibmsys1/z1090/disks/B2DBB2
device 0A8B 3390 3390 /home/ibmsys1/z1090/disks/B2DIS1
device 0A8C 3390 3390 /home/ibmsys1/z1090/disks/B2DIS2
device 0A8D 3390 3390 /home/ibmsys1/z1090/disks/B2IMD1
device 0A8E 3390 3390 /home/ibmsys1/z1090/disks/B2IME1
device 0A8F 3390 3390 /home/ibmsys1/z1090/disks/B2IMU1
device 0A90 3390 3390 /home/ibmsys1/z1090/disks/B2IMU2
device 0A91 3390 3390 /home/ibmsys1/z1090/disks/B2KAN1
device 0A92 3390 3390 /home/ibmsys1/z1090/disks/B2PAGA
device 0A93 3390 3390 /home/ibmsys1/z1090/disks/B2PAGB
device 0A94 3390 3390 /home/ibmsys1/z1090/disks/B2PAGC
device 0A95 3390 3390 /home/ibmsys1/z1090/disks/B2PRD1
device 0A96 3390 3390 /home/ibmsys1/z1090/disks/B2PRD2
device 0A97 3390 3390 /home/ibmsys1/z1090/disks/B2PRD3
device 0A98 3390 3390 /home/ibmsys1/z1090/disks/B2RES2
device 0A99 3390 3390 /home/ibmsys1/z1090/disks/B2USS1
device 0A9A 3390 3390 /home/ibmsys1/z1090/disks/B2USS2
device 0A9B 3390 3390 /home/ibmsys1/z1090/disks/B2W801
device 0A9C 3390 3390 /home/ibmsys1/z1090/disks/B2W802
device 0A9D 3390 3390 /home/ibmsys1/z1090/disks/B2W803
device 0A9E 3390 3390 /home/ibmsys1/z1090/disks/B2W804
device 0A9F 3390 3390 /home/ibmsys1/z1090/disks/B2W805
device 0AA0 3390 3390 /home/ibmsys1/z1090/disks/B2W851
device 0AA1 3390 3390 /home/ibmsys1/z1090/disks/B2W852
device 0AA2 3390 3390 /home/ibmsys1/z1090/disks/B2DBAR
device 0AA3 3390 3390 /home/ibmsys1/z1090/disks/B2W853
device 0AA4 3390 3390 /home/ibmsys1/z1090/disks/B2W854
device 0AA5 3390 3390 /home/ibmsys1/z1090/disks/B2W855
device 0AA6 3390 3390 /home/ibmsys1/z1090/disks/B2W856
device 0AA7 3390 3390 /home/ibmsys1/z1090/disks/B2W857
device 0AA8 3390 3390 /home/ibmsys1/z1090/disks/SARES1
device 0AA9 3390 3390      # Available for dynamic mounts
device 0AAA 3390 3390      # Available for dynamic mounts
device 0AAB 3390 3390      # Available for dynamic mounts
```

Figure 1. Device map example. Device map example

You can verify the device map with the `awsckmap` command. All of the disk volume images that are referenced in the device map must exist before you verify the device map. Assume that the device map file has the following name:

```
/home/ibmsys1/z/myDeviceMap
```

With the name in the preceding example, the device map can be verified with the command:

```
awsckmap /home/ibmsys1/z/myDeviceMap
```

## Sample program to create device map

A sample program that is called `create_devmap.pl` is available in the `ConfigGuideSample` directory where you installed z Systems Development and Test Environment. If Perl is installed on your Linux system, you can use the

create\_devmap.pl program to generate a sample device map that is based on your current decompressed 3390 disk images, memory configuration, and available network parameters.

Consider the output of create\_devmap.pl to be a starting point from which you can create a final device map. The syntax for the create\_devmap.pl command is shown here:

```
perl <pathtocommand>/create_devmap.pl pathtodisks > generateddevmap
```

In the preceding example, *pathtocommand* is the location of the create\_devmap.pl file, and *pathtodisks* is the location of your 3390 disk images. *generateddevmap* is the name of the file to contain the new device map.

If you already have a static IP address that is assigned for your virtual z/OS machine and a z/OS host name that can be resolved to that address by Linux, such as through a connected Domain Name Server or static configuration, you can add the -h <hostname> parameters after the pathtodisks parameter. Adding the parameter causes the script to attempt to generate comments that contain more accurate TCP/IP configuration samples based on your network.

```
perl <pathtocommand>/create_devmap.pl pathtodisks -h  
hostname_of_zos > generateddevmap
```

The create\_devmap.pl program creates a memory line based on existing hardware and configuration of your Linux machine. Verify that the amount of memory that is requested is appropriate for your situation.

The device map that is created by create\_devmap.pl defines OSA devices based on the first Tun/Tap and Wired CHPIDs found that use the **find\_io** command, and a set of sample z/OS TCP/IP definitions that would correspond to the OSA device definitions in the generated device map. These TCP/IP configuration statements can be used as a starting point for your TCP/IP configuration, but probably require changes to match your network. Verify that the device addresses and device names in your final VTAM® definitions, TCP/IP profile, and device map all correspond to the correct network adapter types.

The device map that is created by create\_devmap.pl also contains 3390 device statements for files in the *pathtodisks* directory that are over 800 MB, have six-character names, and are verified to be disk images by the alckd command.

---

## Starting and stopping the z/OS 2.2 ADCD

Learn how to start and stop the z/OS 2.2 ADCD.

z Systems Development and Test Environment is started and stopped, and the z/OS system is IPLed, by using commands that are entered on a Linux console that is running under the user ID that is configured to run z Systems Development and Test Environment.

### Start the z Systems Development and Test Environment

The sample runzpdtd script available in the ConfigGuideSample directory can be used to start z Systems Development and Test Environment with any z/OS distribution.

This script is described in Starting the z Systems Development and Test Environment.



When you run this z/OS 2.2 ADCD, the load parameter that is specified with the -l switch (the -l is a lowercase L) must correspond to a valid load parameter defined in the distribution. For information about the load parameters available with this distribution, and which major subsystems they start, see “z/OS 2.2 ADCD for z Systems Development and Test Environment” on page 20.

**Note:** Each loadparm in this z/OS ADCD has an associated parmlib member that is named COMMNDxx, where xx corresponds to a LOADxx loadparm. That parmlib member defines all of the subsystems that are started when that loadparm is IPLed. The COMMNDxx parmlib member runs an SVTAMxx procedure, which uses a VTAMxx parmlib member to start another set of subsystems. You can see all of the subsystems that are started for all loadparms by looking at the COMMNDxx and VTAMxx parmlib members in ADCD.\*.PARMLIB.

The first time this z/OS distribution is started, start z Systems Development and Test Environment with the CS loadparm. This loadparm initiates a cold start, and does not start other subsystems. After you verify basic z/OS capabilities, you can then customize the system by using the instructions in “Configuring a working z/OS system” on page 6 and create and start different loadparms as needed. As with any z/OS system, warm starts are less disruptive and preserve the JES job spool. Initiate<sup>®</sup> a warm start when possible.

When you perform an IPL of the supplied z/OS distribution system for the first time, you might see some errors during the IPL process. For example, SMF files might be full. If you are prompted with the IXC420D REPLY I TO INITIALIZE SYSPLEX ADCDPL, . . . message, respond with R 0,I, that is, the letter R, a blank, a zero, a comma, and the letter I.

## Stopping the z Systems Development and Test Environment

If possible, always shut down z/OS cleanly. Typically, shutting down cleanly begins by logging off all TSO users, and starting a procedure that shuts down all active subsystems.

This z/OS 2.2 ADCD contains shutdown scripts for most systems available and active in the distribution. They are named SHUTxx, where xx corresponds to the VTAMxx parmlib member that was used to start the subsystems for a particular IPL.

**Note:** Use SHUT00 when the z/OS 2.2 ADCD was started with loadparm CS or WS, and SHUTALL when the z/OS 2.2 ADCD was started with loadparm AL. When an **S SHUTxx** command is issued from the MVS<sup>™</sup> master console, these scripts shut down all systems that were automatically started by the corresponding VTAMxx parmlib member. These shutdown scripts are contained in ADCD.\*.PROCLIB, where \* varies according to the release started.

While the shutdown scripts attempt to stop all active subsystems started by that loadparm, some subsystems might require further input to be stopped. You might have to respond to z/OS console messages, such as when IMS<sup>™</sup>, TSO, or z/OS UNIX are stopped. You can see what programs are still running by entering the D J,L console command. Ensure VTAM and all subsystems are stopped.

After you run the appropriate SHUTxx script and all systems are stopped, stop your JES system. The loadparms in your z/OS 2.2 ADCD distribution always start JES2. A **\$pjes2** command that is entered from the MVS console stops JES2.

After JES ends, z Systems operation can be stopped by entering the **QUIESCE** command. After this command completes, stop the zPDT<sup>®</sup> system by entering this command in the Linux window:

```
$ awsstop
```

This command produces several messages. It might be necessary to press **Enter** to obtain the Linux prompt. Any 3270 windows can be closed.

---

## Configuring a working z/OS system

Learn how to configure a working z/OS 2.2 ADCD system for z Systems Development and Test Environment.

These topics guide you through procedures to help you make customizations to a z/OS 2.2 ADCD. These customizations include establishing TCP/IP connectivity to your z/OS system, increasing your /tmp and /u directories, and optional tasks such as creating new TSO user IDs.

### A brief introduction to z/OS system configuration

In the simplest case, z/OS is configured by changing partitioned data set (PDS) members in the data sets SYS1.PROCLIB, SYS1.PARMLIB, and a few other important data sets including site-specific partitioned data sets.

Most configuration (parmlib) member names consist of a predefined name with a two character suffix added. A common convention is to refer to the suffix as *xx*, so you often see references to LOAD*xx*, IEASYS*xx*, and so on. Configuration files refer to other members by a keyword and suffix number. For example, a member that is called IEASYSRC might identify the main z/OS UNIX configuration file with the line OMVS=RC, which means that z/OS UNIX finds the member that contains its configuration parameters by starting with a predetermined name, BPXPRM, and add the suffix RC (resulting in member name of BPXPRMRC). The keywords in the configuration files *are not* usually the same as the member name prefixes.

|   |
|---|
| <b>Important:</b> Do not directly update data sets such as SYS1.PARMLIB and SYS1.PROCLIB. Some installation-specific libraries are searched before the SYS1 data sets, leaving the SYS1 libraries with IBM supplied defaults. |
|---|

This z/OS 2.2 ADCD defines several sets of alternative libraries. The configurations for the distribution itself are stored in a set of libraries that start with the qualifiers ADCD.\*. The set of libraries that are used to store z Systems Development and Test Environment configurations start with the qualifiers FEU.\*. This z/OS distribution also provides a set of libraries for you to use, which start with the high-level qualifier USER. This z/OS distribution is already set up to read from most of the USER libraries before the FEU.\* libraries and the ADCD.\* libraries. The USER.\* libraries are initially empty, and you can use them for your own changes. They are on a separate volume, B2CFG1. Avoid updating the ADCD.\* and SYS1.\* libraries whenever possible. If you choose to place data in the USER data sets, or create other user data sets or customizations in xxCFG1, these data sets can be easily migrated to a new system. Since volume names change with each release of a z/OS ADCD for z Systems Development and Test Environment, add the xxCFG1 volume to the devmap for the new system, and then copy any customized files back to the newer xxCFG1 volume.

The customizations described here use USER.\* libraries, which tend to be commonly available in any z/OS distribution. While you follow these instructions, all changes are made in USER.\* libraries, except for adding LOADPARM members to SYS1.IPLPARM.

**Note:** Subsystem configuration changes, such as CICS® definitions, also change original libraries such as the CICS CSD.

### The IPL process: LOADxx and IEASYSxx members

When z/OS is started, it looks in data set SYS1.IPLPARM for a member called LOADxx. The xx value is specified in the IPL statement of the start script that was created. A LOADxx member defines various settings to start the system, such as the parmlib concatenation that indicates which data sets are to be searched for other configuration members. The LOADxx member also defines which IEASYSxx member is to be used. IEASYSxx is considered the starting point for system configuration because it contains pointers to other parmlib members that are used during the IPL process.

**Tip:** Create a loadparm that starts the system without pointing to any alternative libraries that contain customized parmlibs, proclibs, and so on. By creating a loadparm if you make a mistake in your customizations that causes z/OS to not start, you can try to perform an IPL of the system with the loadparm that does not point to the alternative libraries. This method gives you TSO access, where you can modify the customizations to correct any mistakes.

If you make a mistake that causes z/OS not to start, you can try to perform an IPL of the system with CS or WS as the last two digits of the LOADPARM. These suffixes start the system with a simpler configuration. CS initiates a cold start, which clears the JES spool, and WS initiates a warm start. For example, to use a LOADPARM of CS, change the IPL command in your startup script to **ipl 0a80 parm 0a82cs**.

In an emergency, you can perform an IPL of the stand-alone system, which provides a basic system, but enables you to change your configuration data sets, because it does not share anything with the normal z/OS setup. The stand-alone system does not contain TCP/IP or Unix system service support. The system cannot be used to install products or apply maintenance through SMP/E. When you use the stand-alone system, you must specify the volume name of data sets you want to edit, since all volumes other than the residence volume for the stand-alone system are not cataloged. Do not edit the stand-alone system configuration. You can perform an IPL of the stand-alone system by mounting volume SARES1 and replacing the IPL statement with **ipl 0A98 parm 0A98SA**. Replace **0A98** with the address of volume SARES1. Use **S SHUTSA** to shut down the SARES1 system.

### PROCLIB: System procedure library

Parmlib members contain only configuration information. The procedures that start the various subsystems and servers are found in a different concatenation called PROCLIB. As an example, this z/OS 2.2 ADCD contains SYS1.PROCLIB, ADCD.\*.PROCLIB, FEU.\*.PROCLIB, and USER.PROCLIB in its PROCLIB concatenation. To include any PROCLIB data set in the PROCLIB concatenation, you must modify the MSTJCLxx member of parmlib and your JES procedure.

For more information, see “Modifying TCP/IP procedures to point to USER.TCPPARMS” on page 14 and Enabling use of USER.PROCLIB and IPLing.

## Configuration overview

Learn how to configure the z/OS system so that you isolate the customized data in your z/OS distribution volumes and establish TCP/IP communications.

The following steps are described:

- Create new z/OS UNIX file systems for /tmp and /u.
- Customize TCP/IP settings to establish network connectivity.

You might also want to make some additional changes that are commonly made.

- Create TSO user IDs.
- Customize ISPF defaults and the ISPF main panel
- Change console defaults
- Streamline startup and shutdown scripts
- Create an NJE connection to existing z/OS systems

Place these customizations on the single volume B2CFG1 volume that already contains your USER.\* libraries. Placing these customizations on a single volume helps with future migrations to new versions of z/OS ADCD distributions.

## Logging on to TSO

After you IPL, you can use the x3270 emulator on the host Linux to start a TSO session.

Enter this command:

```
x3270 -port 3270 localhost &
```

This example shows an alternative format of the x3270 command, which produces a larger screen size:

```
x3270 -model 4 localhost:3270 &
```

You can also use an emulator that is not native to the host Linux. For more information, see “Logging on to TSO from emulators not native to the host Linux” on page 17.

Log on to TSO with a valid user ID in your z/OS distribution. For this distribution, log on with the IBMUSER account, with initial password IBMUSER. You are prompted to change the password. This account has the administrative RACF® privileges that you need for certain customizations. You might want to make a few minor changes to your ISPF session before you start working. If you are accustomed to using TSO naming conventions in ISPF, then to ensure that you do not write out files with unexpected high-level qualifiers, enter the command  
TSO PROFILE PREFIX(tso user id)

## Creating new zFS files for /tmp and /u

Management of z/OS UNIX file systems in z/OS is a complex area. This procedure provides a simplistic design for new file systems. Considerations such as space requirements and alternative mount points might require a more in-depth plan.

This z/OS ADCD provides fairly small file systems for the /tmp and /u directories. Small file systems can cause problems, particularly when you are installing z/OS software by using SMP/E, or when programs create large memory dumps on the z/OS UNIX file system. Allocate 100 primary cylinders and 20 secondary cylinders

for these file systems. If the current file systems for /tmp and /u are not large enough, replace them. To create new file systems for /tmp and /u, create two new zFS files and associate these new files with the /tmp and /u directories. Catalog these two new zFS files on the B2CFG1 volume with your other customizations. Since a user catalog named USERCAT.Z22B.USER is on the B2CFG1 volume of the z/OS 2.2 ADCD as shipped, it can be used for cataloging the two new zFS files. By avoiding use of the master catalog, during migration to a new z/OS ADCD, you then need only to import the user catalog and replicate the alias definitions so that catalog entries are restored. Use this procedure for creating new zFS files for /tmp and /u:

- Create aliases for the high-level qualifiers of the zFS files
- Create the zFS files
- Modify the appropriate BPXPRMxx parmlib member to mount the new zFS files with the /tmp and /u directories
- Copy the existing /tmp and /u directories to the new /tmp and /u directories that are mounted with the new zFS files
- Optionally create a new load parm to contain these changes
- Shut down the system and reIPL

The next topics describe the procedures for each step, including sample JCL where appropriate. In these procedures, the two z/OS UNIX file systems are created with a high-level qualifier of CUST on volume B2CFG1.

### Creating ALIASes for the high-level qualifiers of the zFS files

Start by creating an alias for CUST and any other qualifiers that are used to create data sets here. Create the alias and the file systems on a volume with your other customizations so that it is easy to migrate to a new z/OS distribution.

When you create new users, also create an alias for the user ID in the same catalog. This sample JCL shows you how.

```
//Q12ALIAS JOB (ACCT),MSGCLASS=H,NOTIFY=&SYSUID.
/*-----
//DEFALIAS EXEC PGM=IDCAMS,REGION=0M
//SYSPRINT DD SYSOUT=*
//SYSIN DD *
        DEFINE ALIAS (NAME(CUST) RELATE(USERCAT.Zxxx.USER))
/*
```

### Creating the zFS files

Use the JCL in this topic to create two new zFS files on volume xxCFG1 named CUST.ZFS.U and CUST.ZFS.TMP.

Adjust the space allocations as needed.

```
//Q13ZFS JOB 'IBMUSER',CLASS=A,NOTIFY=&SYSUID,MSGCLASS=H
//ZFSALLOC EXEC PGM=IDCAMS,REGION=0M
//SYSPRINT DD SYSOUT=*
//SYSIN DD *
        DEFINE CLUSTER( -
                NAME(CUST.ZFS.TMP) -
                VOLUME(xxCFG1) -
                LINEAR -
                CYL(100 20) -
                SHAREOPTIONS(3) -
                )
        DEFINE CLUSTER( -
                NAME(CUST.ZFS.U) -
                VOLUME(xxCFG1) -
                LINEAR -
```

```

        CYL(100 20) -
        SHAREOPTIONS(3) -
    )
/*
//ZFSFORMAT EXEC PGM=IOEAGFMT,REGION=0M,COND=(0,LT,ZFSALLOC),
//          PARM='-aggregate CUST.ZFS.TMP -compat'
//SYSPRINT DD SYSOUT=*
//ZFSFORMAT EXEC PGM=IOEAGFMT,REGION=0M,COND=(0,LT,ZFSALLOC),
//          PARM='-aggregate CUST.ZFS.U -compat'
//SYSPRINT DD SYSOUT=*

```

## Modifying BPXPRM00 parmlib member

After you create CUST.ZFS.TMP and CUST.ZFS.U, copy ADCD.Zxxx.PARMLIB(BPXPRM00) into USER.PARMLIB.

Comment out the existing mount of the zFS for tmp, and replace it with a mount of CUST.ZFS.TMP. For example,

```

/* MOUNT    FILESYSTEM('ZFS.&ADCDLVL..TMP') */
/*          TYPE(HFS)                               */
/*          MODE(RDWR) NOAUTOMOVE                     */
/*          MOUNTPOINT('/&SYSNAME../tmp')             */

MOUNT      FILESYSTEM('CUST.ZFS.TMP')
           TYPE(ZFS)
           MODE(RDWR) NOAUTOMOVE
           MOUNTPOINT('/&SYSNAME../tmp')

```

Make a similar change for the mount of /u:

```

/* MOUNT    FILESYSTEM('ZFS.&ADCDLVL..USERS') */
/*          TYPE(HFS)                               */
/*          MODE(RDWR) NOAUTOMOVE                     */
/*          MOUNTPOINT('/u')                         */

MOUNT      FILESYSTEM('CUST.ZFS.U')
           TYPE(ZFS)
           MODE(RDWR) NOAUTOMOVE
           MOUNTPOINT('/u')

```

## Copying the existing /tmp and /u directories

Finally, you must copy the existing /tmp and /u directories to contain the new /tmp and /u file system, and ensure that everyone has proper access permission to the new file systems.

The z/OS UNIX command line can be accessed with the TSO OMVS command, and then you can enter these commands. Be sure to verify that each command works correctly before you proceed to the next command.

```

cd /
mkdir /tempmnt
/usr/sbin/mount -f cust.zfs.tmp /tempmnt
cp -r /tmp/ /tempmnt
ls /tempmnt
chmod 777 /tempmnt
/usr/sbin/unmount /tempmnt
/usr/sbin/mount -f cust.zfs.u /tempmnt
cp -r /u/ /tempmnt
ls /tempmnt          # to verify that the copy worked
chmod 777 /tempmnt
/usr/sbin/unmount /tempmnt
rm -r /tempmnt

```

## Creating a loadparm for customizations

You might want to isolate your customizations into a new loadparm. For example, you can create an RC loadparm that uses your new zFS files for /tmp and /u.

- Instead of modifying BPXPRM00, copy it and rename it to BPXPRMRC, and modify BPXPRMRC.
- Copy the IEASYSxx member that currently starts the subsystems you want to start to USER.PARMLIB. Rename it to IEASYSRC to match the two character loadparm of BPXPRMRC. Update the **OMVS=** parameter to replace the existing two character loadparm with RC.
- Make a copy of the existing LOADxx member in SYS1.IPLPARM that currently starts the subsystems you want to start. Rename it to LOADRC, and store it back into SYS1.IPLPARM. Modify the **SYSPARM** value to RC.

## Shutting down the system and re-IPLing

Shut down the system and perform an IPL. Use your loadparm that points to the modified BPXPRMxx, or your newly created load parm.

When the system restarts, you can enter the z/OS UNIX command line and enter the **df -k** command to ensure that your file systems are being used and mounted correctly.

After the shutdown and re-IPL is complete, you have larger zFS files for /tmp and /u.

## Setting up TCP/IP

z/OS running on z Systems Development and Test Environment can communicate with your network by using TCP/IP. You can use standard 3270 terminal emulators, FTP, Developer for z Systems, and other services to move data to and from your z/OS system.

Since mainframes are confined to data centers, TCP/IP on z/OS does not act as a DHCP client. It does not automatically configure itself to a TCP/IP address supplied by the network. Therefore, it is necessary to configure a few settings to get TCP/IP to communicate with the network. Several methods of configuring TCP/IP are described in zPDT Guide and Reference.

This example uses the method referred to as Scenario 4 in Chapter 7, “LANs” in the zPDT Guide and Reference. This method allows the z/OS system and the Linux system to communicate with your network, each with their own IP address and with the ability to share the ethernet adapter. By each having their own IP address, both systems can simultaneously use functions such as FTP with minimal configuration change. It also eliminates the need to create firewall *holes* for your z/OS ports or provide Network Address Translation functions in your firewall.

**Note:** If these changes are not made, the default TCPIP.PROFILE PROF1 is activated with this z/OS 2.2 ADCD. It activates one OSA with device name ADM1ETP, an IP address of 192.168.0.61, and a default route to 192.168.0.1. Changes required to make this configuration work in your network, by either defining this OSA as a tunnel or defining this OSA to share a Linux ethernet adapter, are explained in the “LANs” chapter of the zPDT Guide and Reference. In either case, with only one OSA activated, you have connectivity restrictions in this configuration. If you define an external OSA without a tunnel OSA, you cannot communicate to the Linux host. If you define a tunnel OSA without an external OSA, all traffic must come through the Linux host, and is subject to Linux routing restrictions, firewalls, and considerations when both Linux and z/OS use the same ports.

The examples show the changes that you must make to the TCP/IP data sets in your z/OS distribution to gain that TCP/IP network connectivity. The examples assume that existing TCP/IP parmlib members and procedures are copied as new members into your USER.\* data sets, and modified. By using this method, the parmlib members and procedures of your original z/OS distribution are unmodified. Alternatively, you can change the existing TCP/IP procedures and parmlib members without creating new members.

TCP/IP and LAN configuration is site-dependent. The exact steps that are outlined here might not work at your site because of local network configuration, firewalls, Linux dependencies, or hardware restrictions. You might need the services of a network administrator to configure z/OS within your network.

## Setting up Linux routing

Before you configure TCP/IP, obtain a static IP address for z/OS. The z/OS IP address must be within the same subnet as your Linux machine. It does not matter if the Linux machine has a DHCP or static IP address if both the z/OS and Linux address are in the same subnet. This z/OS environment is configured to use both the static IP address you obtained and an address of 10.1.1.2. The address of 10.1.1.2 is used to communicate with the Linux machine and cannot be seen by other machines on your network. The following examples show how to configure z/OS so that the external network connects to the machine by address 9.12.200.20, and Linux connects to z/OS by address 10.1.1.2. z/OS can connect to the Linux machine that is using the address 10.1.1.1. The connection between z/OS and Linux is called a tunnel.

**Note:** You can use the `--tunnel_ip` parameter in the `awsosa` stanza to define a local address other than 10.1.1.1. In the customizations below, it is assumed the `--tunnel_ip` parameter is not defined and defaults to 10.1.1.1.

If you use the `create_devmap.pl` program that is described in “Sample program to create device map” on page 3, and you have a z/OS host name that can be resolved to your static z/OS IP address by Linux, such as through a connected Domain Name Server or static configuration, you can add the `-h hostname` parameter to the invocation of the program. This parameter causes `create_devmap.pl` to generate sample contents of z/OS host configuration files that are tailored to your network. It generates the `TCPIP.DATA` and `TCPIP.PROFILE` statements by using the z/OS IP address that corresponds to the entered hostname, and dynamically finds the name server addresses based on the Linux ethernet adapter that is found by using `find_io`. It also generates sample `VTAMLST` members to define two OSAs; a tunnel OSA and an OSA to be used with one of the Linux ethernet adapters. The contents are shown as comments at the end of the generated device map and are examples only. Because of the variability and complexity of network configuration, the samples that are shown in the generated device map might need modification to work in your environment.

This example assumes that you have the following OSA definitions in your devmap to define the tunnel OSA and one ethernet OSA to be used by TCP/IP:

```
[manager]          # define network adapter (OSA) for communication with Linux
name awsosa 0024 --path=A0 --pathtype=OSD --tunnel_intf=y  # QDIO mode
device 400 osa osa
device 401 osa osa
device 402 osa osa
[manager]          # define network adapter (OSA) for communication with network
```



```
name awsosa 22 --path=F0 --pathtype=OSD    # QDIO mode
device 404 osa osa
device 405 osa osa
device 406 osa osa
```

## Modifying TCPPARMS files

Learn how to modify two TCPPARMS files to establish TCP/IP connectivity by using an IP address that is defined for z/OS: PROFILE.TCPIP and TCPIP.DATA.

### PROFILE.TCPIP:

Copy ADCD.Z22B.TCPPARMS(PROF2) to USER.TCPPARMS(PROFILE) and modify the DEVICE, LINK, HOME, and route definitions to use the OSAs defined in your devmap, with the addresses and netmask information that is correct for your network. For example, given a z/OS IP address of 9.12.200.20, and a netmask of 255.255.255.0, a TCP/IP PROFILE member might look like the following example.

**Note:** Comments and other statements were removed for brevity. Also, the IP address of the Linux system is not needed here. The gateway address usually ends in .1 or .0, but that might be different on your network.

This example also includes the definitions for the tunnel, the 10.1.1.2 address, which is used to communicate with z/OS from the Linux machine.

```
ARPAGE 5
  DATASETPREFIX TCPIP
  AUTOLOG 5
    FTPD JOBNAME FTPD1    ; FTP Server
    PORTMAP                ; Portmap Server
  ENDAUTOLOG
  PORT
    ((( ports removed for brevity )))
  SACONFIG DISABLED
    DEVICE PORTA MPCIPA
    LINK ETH1  IPAQENET PORTA
    HOME 10.1.1.2 ETH1

    DEVICE PORTB MPCIPA
    LINK ETH2  IPAQENET PORTB
    HOME 9.12.200.20 ETH2

  BEGINROUTES
  ROUTE 10.0.0.0      255.0.0.0      =      ETH1  MTU 1492
  ROUTE 9.12.200.0    255.255.255.0  =      ETH2  MTU 1492
  ROUTE DEFAULT      9.12.200.1      =      ETH2  MTU 1492
  ENDROUTES
  ITRACE OFF
  IPCONFIG NODATAGRAMFWD
  UDPCONFIG RESTRICTLOWPORTS
  TCPCONFIG RESTRICTLOWPORTS
  START PORTA
  START PORTB
```

Copy ADCD.Z112S.VTAMLST(OSATRL2) to USER.VTAMLST(OSATRL2) and remove any comments within it so that it looks like the next example.

The device name in the TCP/IP profile member must match the port names that are specified in USER.VTAMLST(OSATRL2). In this example, these port names are PORTA and PORTB. Also, verify that your devmap correctly defines the device addresses in the READ, WRITE, and DATAPATH statements of USER.VTAMLST(OSATRL2). For more information about the device map, see “Defining the device map for z/OS 2.2 ADCD” on page 1.

```

OSATRL1 VBUILD TYPE=TRL
      OSATRL1E TRLE LNCTL=MPC,READ=(0400),WRITE=(0401),DATAPATH=(0402),      X
                                PORTNAME=PORTA,                                X
                                MPCLEVEL=QDIO
      OSATRL2E TRLE LNCTL=MPC,READ=(0404),WRITE=(0405),DATAPATH=(0406),      X
                                PORTNAME=PORTB,                                X
                                MPCLEVEL=QDIO

```

To activate this configuration, copy ADCD.Z112S.VTAMLST(ATCCON00) to USER.VTAMLST(ATCCON00) and change the word OSATRL1 to OSATRL2.

### TCPIP.DATA:

Copy ADCD.Z22B.TCPPARMS(TCPDATA) to USER.TCPPARMS and set the HOSTNAME, DOMAINORIGIN, and NSINTERADDR values.

```

TCPIPJOBNAME TCPIP
      HOSTNAME RDT900
      DOMAINORIGIN RTP.IBM.COM
      DATASETPREFIX TCPIP
      NSINTERADDR 9.0.0.1
      NSINTERADDR 9.0.0.11
      RESOLVEVIA UDP
      LOOKUP LOCAL DNS
      RESOLVERTIMEOUT 10
      RESOLVERUDPRETRIES 1
      ALWAYSSTO NO

```

The z/OS 2.2 ADCD ships with a HOSTNAME of S0W1 and a DOMAINORIGIN of DAL-EBIS.IHOST.COM. These work with the shipped WebSphere® Application Server configuration. If you chose to define a different HOSTNAME and DOMAINORIGIN, and used the create\_devmap.pl program with the -h option and your chosen HOSTNAME to create your devmap, the output devmap will contain the customized TCPIP.DATA parameters for HOSTNAME and DOMAINORIGIN.

If you choose a HOSTNAME or DOMAINORIGIN arbitrarily, be sure that the DOMAINORIGIN is not a real domain name and that the combination of the HOSTNAME and DOMAINORIGIN does not constitute an existing DNS name. Use the Linux ping or nslookup commands to ensure that your choice of names is not found by your DNS server. Identifying your computer as another computer, or as a member of an existing but incorrect domain, can cause problems that are difficult to diagnose, such as timeouts, pauses, and connection failures in many areas, including 3270 connections and z Systems Development and Test Environment. Some systems, including components of z Systems Development and Test Environment, require that z/OS can locate itself by name.

Ensure that the NSINTERADDR parameter correctly identifies a DNS server. Incorrect name server specifications can also cause long delays and errors that are difficult to diagnose. Stand-alone systems should not specify NSINTERADDR values.

If you cannot use a Domain Name Server (DNS) to resolve IP addresses of other systems or of the z/OS system, you can create a local hosts file and refer to it with a GLOBALIPNODES statement. The setup of this file is described in detail in *TCP/IP implementation volume 1: Base functions* (SG24-7798).

### Modifying TCP/IP procedures to point to USER.TCPPARMS

An easy way to use ISPF to find Procedures that reference the TCPPARMS data sets is to display a member list of each proclib data set in your active MSTJCLxx parmlib member (typically MSTJCL00), and then type these commands:

```

SRCHFOR TCPPARMS
SORT PROMPT

```

Copy the following members from ADCD.Z22B.PROCLIB to USER.PROCLIB. Be careful not to replace any members you already changed in USER.PROCLIB.

```
FTPD
PORTMAP
TCPIP
RESOLVER
NFSC
NFSS
```

Modify each member to change references from the existing TCPPARMS data set to USER.TCPPARMS for any members that you duplicated in USER.TCPPARMS. Do not change the member names except as noted in the TCP/IP procedure.

For example, locate this line in FTPD:

```
//SYSTCPD DD DISP=SHR,DSN=ADCD.&SYSVER..TCPARMS(TCPDATA)
```

Change it to

```
//*SYSTCPD DD DISP=SHR,DSN=CUST.TCPPARMS(TCPDATA)
//SYSTCPD DD DISP=SHR,DSN=USER.TCPPARMS(TCPDATA)
```

Remember a modified TCP/IP profile member name was placed in USER.TCPPARMS, so the PROFILE DD statement is similar to this example:

```
//PROFILE DD DISP=SHR,DSN=USER.TCPPARMS(PROFILE)
```

If you prefer to set up system-wide use of a common set of TCP/IP settings, set up the RESOLVER procedure to point to your TCP/IP definitions. Create member USER.TCPPARMS(RESOLVER) to contain the following statements.

```
GLOBALTCPDATA('USER.TCPPARMS(TCPDATA)')
GLOBALIPNODES('USER.TCPPARMS(IPNODES)')
COMMONSEARCH
```

Create member USER.TCPPARMS(IPNODES) to contain the following statements similar to the following but customized with your network names and address. If you used the create\_devmap.pl program with the **-h** option to create your devmap, the output devmap contains the customized IPNODES file. The format of each entry in the IPNODES file is IP address followed by one or more host names. The order of the entries is not significant.

```
# This first entry is the ip address of the z/OS host with its associated hostnames
# In this example, two hostnames are configured; a shortened alias and a fully
# qualified hostname.
# Only one hostname is required, typically the fully qualified name
#
9.12.200.0 RDT900 RDT90.IBM.COM
#
# This entry is the ip address of the OSA tunnel to the Linux host.
# The hostname should be the hostname of the Linux operating system.
# Multiple hostnames may be configured if needed
#
10.1.1.1 LINUX
#
# Typically, 127.0.0.1 is configured as hostname LOCALHOST
#
127.0.0.1 LOCALHOST
```

Copy ADCD.Z22BZ22B.PROCLIB(RESOLVER) to USER.PROCLIB(RESOLVER), and change the SETUP DD statement from:

```
//SETUP DD DISP=SHR,DSN=ADCD.Z21F.TCPPARMS(GBLRESOL),FREE=CLOSE
```

To

```
//SETUP DD DISP=SHR,DSN=USER.TCPPARMS(RESOLVER),FREE=CLOSE
```

### Modifying VTAMLST members:

Create a VTAMLST member to define a TRL major node that matches the OSAs you are using. Member OSATRL2 in ADCD.\*.VTAMLST matches the sample devmap. If you create a new member to match your OSAs, add that member to USER.VTAMLST. To activate this major node when VTAM starts, add the VTAMLST member name to the VTAM configuration list (member ATCCONxx in VTAMLST) with which you start VTAM.

```
OSATRL1 VBUILD TYPE=TRL
OSATRL1E TRLE LNCTL=MPC,READ=(400),WRITE=(401),DATAPATH=(402),      X
                PORTNAME=PORTA,MPCLEVEL=QDIO
OSATRL2E TRLE LNCTL=MPC,READ=(404),WRITE=(405),DATAPATH=(406),      X
                PORTNAME=PORTB,MPCLEVEL=QDIO
```

## Optional tasks

Learn about optional configuration tasks for z Systems Development and Test Environment.

### Creating a user volume

Some users might want to create one or more user volumes to isolate configuration data for some of their products. For example, you might want to isolate all of your configuration files for IBM z Systems Development and Test Environment or you might want a new volume for a particular application or a newer version of an existing product. To create a new volume, do these following steps. This example creates a volume that is named USER00, placing it in the same directory as the other z/OS 2.2 ADCD disks:

- Create a volume in emulated 3390 format.

```
alckkd /home/ibmsys1/z1090/disks/USER00 -d3390-9
```

**Note:** You can use -d3390-3 or other volume types and sizes if wanted. See the alckkd command section of the

- Add the new volume to your device map

```
device 0CCC 3390 3390 /home/ibmsys1/z1090/disks/USER00
```

- After you start IBM z Systems Development and Test Environment, initialize the new volume

- Vary the volume offline

```
V 0CCC,OFFLINE
```

- Create and submit a member of a partitioned data set with the following JCL

**Note:** Customize the job card and VTOC parameters as needed. The VTOC parameters for a 3390-3 and a 3390-9 are shown.

```
//J01INIT JOB (ACCT),MSGCLASS=H,NOTIFY=&SYSUID.,REGION=0M
/* MOD-3: VTOC(0,1,974) INDEX(65,0,50)
/* MOD-9: VTOC(0,1,2939) INDEX(196,0,150)
//FORMAT EXEC PGM=ICKDSF
//SYSPRINT DD SYSOUT=*
//SYSIN DD *
        INIT UNIT(CCC) NOVALIDATE NVFY VOLID(USER00) PURGE -
        VTOC(0,1,2939) INDEX(196,0,150)
/*
```

- If prompted on the console, reply U to the console command (R xx,U) to allow MVS to alter the contents of the volume. This job ends with return code 0.

- Vary the volume online:

```
V 0CCC,ONLINE
```

- Create a user catalog for the new volume by creating and submitting a member of a partitioned data set with the following JCL. Modify the job card as needed.

```
//J02CATLG JOB (ACCT),MSGCLASS=H,NOTIFY=&SYSUID.
//DEFCAT EXEC PGM=IDCAMS,REGION=0M
//SYSPRINT DD SYSOUT=*
//SYSIN DD *
DEFINE USERCATALOG (NAME(USERCAT.VUSER00) ICFCATALOG -
CYLINDERS(10 5) VOLUME(USER00) )
/*
```

**Note:** If no user catalog is used, all cataloged data sets are cataloged in the master catalog, which is replaced when you upgrade your z/OS system. To avoid placing entries in the master catalog, you can create aliases for high-level qualifiers for data sets that you want to catalog in the USER00 user catalog. During migration, you need only to import the user catalog and replicate the alias definitions so that catalog entries are restored.

### Ensure that all new data sets are written to a new volume

You can increase storage for all new permanent data sets by adding one or more newly created volumes to the volume attribute list (VATLSTxx member of the parmlib). The suffix xx of your volume attribute list parmlib member is the value found for the VAL= parameter in the IEASYSxx parmlib member corresponding to your loadparm. Copy the appropriate VATLSTxx member of the parmlib from AD CD.\*.PARMLIB to USER.PARMLIB and add the volume to any existing definitions as shown. In this example, the new USER00 volume is added with a permanently resident mount attribute, a use attribute of storage, and mount messages to be entered. The contents of this member must be in specific columns, so be sure to use the copied contents as a model. See the VATLSTxx section of the z/OS 2.2.0 MVS Initialization and Tuning Reference for the format and explanation of all fields and parameters in the volume attribute list.

```
VATDEF IPLUSE(PRIVATE),SYSUSE(PRIVATE)
B2SYS1,0,0,3390      ,Y
USER00,0,0,3390      ,Y
```

Changes to VATLST00 will not be effective until you perform the next IPL.

### Logging on to TSO from emulators not native to the host Linux

After TCP/IP connectivity is established, you can use your favorite 3270 emulator software, such as IBM Personal Communications Manager (PCOMM), to connect to the non-SNA (coax) 3270 device emulator that is provided by z Systems Development and Test Environment. When you connect from outside the Linux system that is hosting z Systems Development and Test Environment, use the Linux TCPIP address and 3270 as port. (The actual port number is defined in the device map.)

### Creating TSO user IDs

Learn how to create TSO user IDs for running z Systems Development and Test Environment.

A z/OS AD CD for IBM z Systems Development and Test Environment provides a number of predefined user IDs. “z/OS 2.2 AD CD for z Systems Development and Test Environment” on page 20 contains the list of all predefined user IDs available to you.

If more TSO user IDs are required, they can be created through a series of commands. Typically, you want to use user IDs that have OMVS segments and an associated z/OS UNIX user directory when you are running Developer for z Systems. The example commands that are shown here create a user ID in the RDZUSERS group with an OMVS segment. Replace #userid, #name, and #password with appropriate values, and do not remove the quotation marks in the commands.

From a CLIST, REXX exec, or TSO command line, enter the following commands. The commands create the user ID, provide an OMVS segment, and assign an account number, default logon procedure, and region size. They also protect data sets with a high-level qualifier that belongs to the user from being accessed by other users. Finally, the commands create an alias in the master catalog to indicate that the user's data sets are cataloged in the user catalog on volume S1CUST. Be sure that the substitutions in the HOME( ) and PROGRAM( ) parameters are in lowercase.

```
ADDGROUP RDZUSERS OMVS(AUTOGID)
  ADDUSER #userid DFLTGRP(RDZUSERS) NAME('#name') PASSWORD(#password)
  ALTUSER #userid OMVS(HOME(/u/#userid) PROGRAM(/bin/sh) AUTOUID)
  ALTUSER #userid TSO(ACCTNUM(ACCT#) PROC(TSOLOGON) SIZE(4096) COMMAND('ISPF'))
  ADDSD '#userid.*' UACC(NONE)
  PERMIT ACCT# CLASS(ACCTNUM) ID(#userid) ACCESS(READ)
  DEFINE ALIAS (NAME('#userid') RELATE('USERCAT.Z22B.USER'))
```

The new user's z/OS UNIX directory must be created. From a z/OS UNIX command line, type the following commands. You can access z/OS UNIX by typing TSO OMVS on the command line of any ISPF screen. You exit z/OS UNIX with the exit command. Again, replace #userid with the name of the new user ID in lowercase.

```
mkdir /u/#userid
chown #userid:RDZUSERS /u/#userid
```

## Defining a new logon procedure

A common customization in z/OS systems is to alter the logon procedure that TSO users use. Do not alter the ISPFPROC logon procedure because errors might prevent you from being able to fix problems later on.

Create USER.PROCLIB(TSOLOGON) based on ADCD.Z22B.PROCLIB(ISPFPROC), and make your modifications to TSOLOGON instead of ISPFPROC. Be sure to change the identifier on the EXEC from ISPFPROC to TSOLOGON and to override the default VOLSER used by the ISPFCL CLIST.

```
//TSOLOGON EXEC PGM=IKJEFT01,REGION=0M,DYNAMNBR=175,
//          PARM='%ISPFCL VOL(B2CFG1)'
```

To allow all users to use the TSOLOGON procedure, enter the following TSO commands.

```
RDEFINE TSOPROC TSOLOGON UACC(READ)
SETROPTS RACLIST(TSOPROC) REFRESH
```

## Altering system startup and shutdown scripts

This z/OS 2.2 ADCD has shutdown scripts that contain a series of commands to shut down all active subsystems.

You might want to make these changes to the scripts.

The shutdown scripts stop OMVS automatically. Explicitly stopping zFS can expedite the shutdown process, but requires a response to a prompt on the operator console. If you want to stop zFS before you shut down OMVS, add this change:

```
F OMVS,STOPPFS=ZFS
F OMVS,SHUTDOWN
```

Some startup and shutdown scripts have PAUSE commands that you might find are too long or too short for your system. Many can be safely changed to pause for a shorter amount of time.

You can change startup scripts the same way. Other changes might include not starting particular subsystems, changing pause times, and so forth.

## Defining JES NJE connectivity

Your z/OS distribution is a stand-alone system with no connection to other z/OS systems. However, you might want to connect it to one or more of your z/OS systems to transfer data to customize and use the z Systems Development and Test Environment system.

Beginning with z/OS 1.7, JES supports NJE over TCP/IP, which makes setting up a connection between two systems an easy task. The following operator commands, to be run on the z Systems Development and Test Environment system, name the local system RUT0 and define a connection to M168.

```
$TNODE(Z21S),NAME=RUT0
$TLINE1,UNIT=TCP
$SLINE1
$ADDNETSRV1,SOCKET=LOCAL
$SNETSERV1
$TNODE2,NAME=M168
$ADDSOCKET(REMOTE),NETSRV=1,LINE=1,NODE=2,IPADDR=M168.RTP.IBM.COM
$SN,SOCKET=REMOTE
```

Give similar operator commands on the M168 system to complete the setup. Since this system is an existing system, the command to define the local node name was skipped. The following commands also assume that M168 does not have spare line or node definitions, so new ones (line 5 and node 20) are created.

```
$ADDLINE5,UNIT=TCP
$SLINE5
$ADDNETSRV1,SOCKET=LOCAL
$SNETSERV1
$TNJEDEF,NODENUM=20
$TNODE20,NAME=RUT0
$ADDSOCKET(REMOTE),NETSRV=1,LINE=5,NODE=20,IPADDR=RDz9100.RTP.IBM.COM
$SN,SOCKET=REMOTE
```

The z Systems Development and Test Environment system can use the existing NJE definitions on the M168 system to connect to other NJE nodes in your network. Enter the following operator commands on the z Systems Development and Test Environment system to connect to the IPO1 system (node 3) through the previously defined M168 system (node 2).

```
$TNODE3,NAME=IPO1
$ADDCONNECT,NODEA=2,NODEB=3
```

For more information, see the “Network Job Entry” section of the *z/OS JES2 Initialization and Tuning Guide*.

---

## z/OS 2.2 ADCD for z Systems Development and Test Environment

Learn what's new with this distribution from past z/OS distributions, the products that are included with this distribution, the volumes that can be downloaded and their general contents, the migration guidelines, including the parmlib and proclib structure of the distribution, the loadparms available with this distribution and which subsystems they start, the user IDs and passwords available with the system, and the maintenance service levels of the products.

### Customization help and location of product PGMDIRs

Although the products in this ADCD were customized, you might find some products are not fully customized or are customized with options that you need to change.

Included in this release are files in the format of *p.SVSC.l* where *p* is the product high-level qualifier and *l* is the library name. The purpose of these files is to provide PGMDIRs, readme file, and installation instructions. This ADCD is built from a driver system that uses different volume and library names. Thus, the names that are referenced in the SVSC files are different from the ADCD. You might need to make translations on names to implement in the ADCD. Included on DVD1 on the RES1 volume are data sets with an HLQ of MVS.Z0SRxx that document MVS. The MVS PGMDIR is contained in this grouping.

### What's new in this release

Learn which modifications and enhancements are incorporated into this z/OS 2.2 ADCD for z Systems Development and Test Environment July 2016 edition.

- z/OS 2.2 and related products were upgraded to PUT1512 / RSU1602.
- The following products were removed:
  - IBM Ported Tools for z/OS – Xvfb
  - IBM 31-bit and 64-bit SDK for z/OS, Java™ Technology Edition V6.0.0
  - IBM 31-bit and 64-bit SDK for z/OS, Java Technology Edition V6.0.1
  - IBM 31-bit and 64-bit SDK for z/OS, Java Technology Edition V7.0.0
  - IMS Transaction and Database Servers V12.1
  - CICS Transaction Server for z/OS V4.2
- The following products are upgraded with the latest available release/mod level:
  - Rational Developer for z Systems V9.5.1
  - IBM Rational Team Concert™ V6.0.1
  - IBM UrbanCode™ Deploy v6.2.1
  - CICS Interdependency Analyzer for z/OS V5.3.0
  - CICS Deployment Assistant for z/OS V5.3.0
  - IBM IMS Enterprise Suite for z/OS, V3.2.0
  - IBM DB2® Accessories Suite for z/OS, V3.3
  - IBM WebSphere Application Server V8.5.5.8
  - IBM Tivoli® NetView® for z/OS V6.2.1
  - IBM Tivoli Management Services on z/OS V6.3
  - IBM Tivoli Workload Scheduler for z/OS V9.3
  - IBM HTTP Server V9.0
- The following products are added to the ADCD z/OS 2.2 July 2016 Edition:
  - CICS Transaction Server for z/OS V5.3



- IMS Transaction and Database Servers V14
- IBM z<sup>TM</sup>/OS Connect Enterprise Edition V2.0
- IBM Sterling Connect:Direct<sup>®</sup> for z/OS V5.2
- IBM Tivoli OMEGAMON<sup>®</sup> Performance Management Suite for z/OS V9.3\*
- IBM Dataset Commander for z/OS V8.1
- IBM Explorer for z/OS Aqua V3.0
- The volume size of all of z/OS base, z/OS products, and middleware was increased to mod-9 (10,000 cylinders) to provide more free space for expansion.

## Products contained in this release

Lists the products contained in this release.

### z/OS 2.2 July 2016 Edition

Lists the products available in the z/OS 2.2 July 2016 Edition.

| Product Number | Description                                       | Fmid    | Dependent FMID | HLQ  |
|----------------|---|---------|----------------|------|
| 5650-ZOS       | GDDM-PGF  | HGD3201 | HGD3201        | SYS1 |
| 5650-ZOS       | High Level Assembler Toolkit                      | HMQ4160 | JMQ416A        | SYS1 |
| 5650-ZOS       | Infoprint Server - IP PrintWay <sup>TM</sup> Base | HMOS705 | HMOS705        | SYS1 |
| 5650-ZOS       | BULK DATA TRANSFER SNA NJE                        | HBD6602 | JBD6202        | SYS1 |
| 5650-ZOS       | C/C++ HOST PERFORMANCE ANALYZER                   | H24P111 | H24P111        | SYS1 |
| 5650-ZOS       | BULK DATA TRANSFER BASE                           | HBD6602 | JBD6201        | SYS1 |
| 5650-ZOS       | RMF <sup>TM</sup> Base                            | HRM77A0 | HRM77A0        | SYS1 |
| 5650-ZOS       | DFSORT Base                                       | HSM1M00 | HSM1M00        | SYS1 |
| 5650-ZOS       | SDSF Base   | HQX77A0 | HQX77A0        | SYS1 |
| 5650-ZOS       | Security Server - RACF Base                       | HRF77A0 | HRF77A0        | SYS1 |
| 5650-ZOS       | XL C/C++ Base                                     | HLB77A0 | HLB77A0        | SYS1 |
| 5650-ZOS       | JES3  | HJS77A0 | HJS77A0        | SYS1 |
| 5650-ZOS       | Hardware Configuration Manager                    | HCM1F10 | HCM1F10        | SYS1 |
| 5650-ZOS       | Infoprint Server - NetSpool Base                  | HNET7A0 | HNET7A0        | SYS1 |
| 5650-ZOS       | Infoprint Server - Print Interface Base           | HOP17A0 | HOP17A0        | SYS1 |

|          |   |         |         |      |
|----------|---|---------|---------|------|
| 5650-ZOS | BOOKMANAGER<br>READ/MVS -<br>ENU                            | HBKM300 | JBKM310 | SYS1 |
| 5650-ZOS | ESCON Director  | HSWF100 | HSWF100 | SYS1 |
| 5650-ZOS | GDDM NLS<br>ENU   | HGD3200 | JGD3219 | SYS1 |
| 5650-ZOS | OSA/SF  | H0GI400 | H0GI400 | SYS1 |
| 5650-ZOS | Distributed File<br>Service Base                            | H0H2410 | H0H2410 | SYS1 |
| 5650-ZOS | IBM Alternate<br>Library for<br>REXX on zSeries             | HWJ9143 | HWJ9143 | SYS1 |
| 5650-ZOS | Metal C Runtime<br>Library                                  | HSD7780 | HSD7780 | SYS1 |
| 5650-ZOS | Integrated<br>Security Services<br>- Open Crypto<br>Enhance | HRO7740 | HRO7740 | SYS1 |
| 5650-ZOS | GDDM NLS<br>ENU   | HGD3200 | HGD3200 | SYS1 |
| 5650-ZOS | Library Server  | HBKQ400 | HBKQ400 | SYS1 |
| 5650-ZOS | Integrated<br>Security Services<br>- Enterprise<br>Identity | HIT7750 | HIT7750 | SYS1 |
| 5650-ZOS | BDT   | HBD6602 | HBD6602 | SYS1 |
| 5650-ZOS | SMP/E Base  | HMP1J00 | HMP1J00 | SYS1 |
| 5650-ZOS | High Level<br>Assembler Base                                | HMQ4160 | HMQ4160 | SYS1 |
| 5650-ZOS | z/OS Font<br>Collection -<br>Chinese,<br>Japanese, Korean   | HFNT11J | HFNT11J | SYS1 |
| 5650-ZOS | IOCP  | HIO1104 | HIO1104 | SYS1 |
| 5650-ZOS | z/OS Font<br>Collection                                     | HFNT110 | HFNT110 | SYS1 |
| 5650-ZOS | BOOKMANAGER<br>READ/MVS -<br>ENU                            | HBKM300 | HBKM300 | SYS1 |
| 5650-ZOS | SMP/E Planning<br>and Migration<br>Assistant<br>Software In | HBCNC00 | HBCNC00 | SYS1 |
| 5650-ZOS | FFST™   | HFST101 | HFST101 | SYS1 |
| 5650-ZOS | 3270 PC File<br>Transfer<br>Program                         | HFX1112 | HFX1112 | SYS1 |
| 5650-ZOS | SMP/E Planning<br>and Migration<br>Assistant                | HBCND0B | HBCND0B | SYS1 |

|          |  |         |         |      |
|----------|--|---------|---------|------|
| 5650-ZOS | ICKDSF - Device Support Facilities, Base           | EDU1H01 | EDU1H01 | SYS1 |
| 5650-ZOS | Environmental Record Editing and Printing          | EER3500 | EER3500 | SYS1 |
| 5650-ZOS | MICR/OCR   | EMI2220 | EMI2220 | SYS1 |
| 5650-ZOS | TIOC   | ETI1106 | ETI1106 | SYS1 |
| 5650-ZOS | ICKDSF - Device Support Facilities, ISMF/MODS      | EDU1H01 | FDU1H07 | SYS1 |
| 5650-ZOS | ICKDSF - Device Support Facilities, ISMF/ENU       | EDU1H01 | FDU1H08 | SYS1 |
| 5650-ZOS | BCP Base   | HBB77A0 | HBB77A0 | SYS1 |
| 5650-ZOS | z/OSMF Software Deployment                         | HSMA224 | HSMA224 | SYS1 |
| 5650-ZOS | Runtime Library Extensions Base                    | HTV77A0 | HTV77A0 | SYS1 |
| 5650-ZOS | BCP - Support for Unicode Base                     | HUN77A0 | HUN77A0 | SYS1 |
| 5650-ZOS | z/OSMF Plug-in A                                   | HSMA228 | HSMA228 | SYS1 |
| 5650-ZOS | z/OSMF Plug-in B                                   | HSMA229 | HSMA229 | SYS1 |
| 5650-ZOS | z/OSMF Incident Log                                | HSMA225 | HSMA225 | SYS1 |
| 5650-ZOS | z/OSMF Configuration Assistant                     | HSMA22A | HSMA22A | SYS1 |
| 5650-ZOS | z/OS File System Base                              | HZFS420 | HZFS420 | SYS1 |
| 5650-ZOS | z/OSMF Core Functions                              | HSMA220 | HSMA220 | SYS1 |
| 5650-ZOS | z/OSMF ISPF  | HSMA221 | HSMA221 | SYS1 |
| 5650-ZOS | z/OSMF Plug-in C                                   | HSMA22B | HSMA22B | SYS1 |
| 5650-ZOS | IBM Tivoli Directory Server for z/OS Base          | HRSL420 | HRSL420 | SYS1 |
| 5650-ZOS | Communications Server SNA                          | HVT6220 | HVT6220 | SYS1 |
| 5650-ZOS | IBM z/OS Management Facility - Capacity Provisioni | HSMA226 | HSMA226 | SYS1 |

|          |   |         |         |      |
|----------|---|---------|---------|------|
| 5650-ZOS | Integrated Security Services- Network Authenticatio | HSWK420 | HSWK420 | SYS1 |
| 5650-ZOS | TSO/E Base  | HTE77A0 | HTE77A0 | SYS1 |
| 5650-ZOS | z/OSMF Workflow                                     | HSMA227 | HSMA227 | SYS1 |
| 5650-ZOS | IBM z/OS Management Facility - RM                   | HSMA222 | HSMA222 | SYS1 |
| 5650-ZOS | z/OSMF WLM  | HSMA223 | HSMA223 | SYS1 |
| 5650-ZOS | z/OS UNIX System Services Application Services Bas  | HOT77A0 | HOT77A0 | SYS1 |
| 5650-ZOS | Common Information Model                            | HPG77A0 | HPG77A0 | SYS1 |
| 5650-ZOS | BCP - Program Management Binder                     | HPM77A0 | HPM77A0 | SYS1 |
| 5650-ZOS | BCP - Capacity Provisioning                         | HPV77A0 | HPV77A0 | SYS1 |
| 5650-ZOS | OpenSSH for z/OS                                    | HOS2220 | HOS2220 | SYS1 |
| 5650-ZOS | Communications Server X11R4 XWindows                | HIP6220 | JIP622X | SYS1 |
| 5650-ZOS | TSO/E ENU   | HTE77A0 | JTE77AE | SYS1 |
| 5650-ZOS | Language Environment® Base                          | HLE77A0 | HLE77A0 | SYS1 |
| 5650-ZOS | Cryptographic Services - PKI Services               | HKY77A0 | HKY77A0 | SYS1 |
| 5650-ZOS | IBM Knowledge Center for z/OS                       | HKCZ100 | HKCZ100 | SYS1 |
| 5650-ZOS | JES2 Base   | HJE77A0 | HJE77A0 | SYS1 |
| 5650-ZOS | Communications Server IP                            | HIP6220 | HIP6220 | SYS1 |
| 5650-ZOS | IBM HTTP Server                                     | HHAP90P | HHAP90P | SYS1 |
| 5650-ZOS | ISPF Base   | HIF7P02 | HIF7P02 | SYS1 |
| 5650-ZOS | Network File System Server and Client               | HDZ222N | HDZ222N | SYS1 |
| 5650-ZOS | Data Facility System Managed Storage Base & ENU     | HDZ2220 | HDZ2220 | SYS1 |

|          |  |         |         |        |
|----------|--|---------|---------|--------|
| 5650-ZOS | Enhanced Cryptographic Support - ICSF              | HCR77B0 | HCR77B0 | SYS1   |
| 5650-ZOS | Hardware Configuration Definition Base             | HCS77A0 | HCS77A0 | SYS1   |
| 5650-ZOS | Cryptographic Services - System SSL Base           | HCPT420 | HCPT420 | SYS1   |
| 5650-ZOS | Cryptographic Services - OCSF Base                 | HCRY740 | HCRY740 | SYS1   |
| 5650-ZOS | Communications Server Security Level 3             | HIP6220 | JIP622K | SYS1   |
| 5650-ZOS | z/OS Security Level 3 - System SSL Security Level  | HCPT420 | JCPT421 | SYS1   |
| 5650-ZOS | z/OS Security Level 3 - IBM TDS for z/OS Security  | HRSL420 | JRSL421 | SYS1   |
| 5650-ZOS | z/OS Security Level 3 - Network Authentication Srv | HSWK420 | JSWK421 | SYS1   |
| 5650-ZOS | z/OS Security Level 3 - OCSF Security Level 3      | HCRY740 | JCRY741 | SYS1   |
| 5655-P97 | Encryption Facility DFSMSdss Encryption            | HCF773D | HCF773D | SYS1   |
| 5655-P97 | Encryption Facility Encrypt Ser                    | HCF7740 | HCF7740 | SYS1   |
| 5655-W97 | IBM WebSphere MQ for z/OS USS                      | HMS8000 | JMS8008 | CSQ800 |
| 5655-W97 | IBM WebSphere MQ for z/OS Base                     | HMS8000 | HMS8000 | CSQ800 |
| 5655-W97 | IBM WebSphere MQ for z/OS US English               | HMS8000 | JMS8001 | CSQ800 |
| 5655-W97 | IBM WebSphere MQ for z/OS Uppercase English ENP    | HMS8000 | JMS8004 | CSQ800 |

| Product Number | Description                               | Fmid    | Dependent FMID | HLQ    |
|----------------|---|---------|----------------|--------|
| 5655-M32       | UPLOAD FOR z/OS                           | HPRF417 | HPRF417        | APS450 |
| 5655-M32       | PSF for z/OS Base                         | HPRF450 | HPRF450        | APS450 |
| 5655-M32       | Download for z/OS                         | HPRF450 | JPRF452        | APS450 |
| 5655-M32       | Code Page                                 | H0HL15C | J0HL144        | APS450 |
| 5655-M32       | Code Page                                 | H0HL15C | H0HL15C        | APS450 |
| 5655-M32       | Code Page                                 | H0HL15D | H0HL15D        | APS450 |
| 5655-M32       | Code Sample                               | H0HL140 | H0HL140        | APS450 |
| 5655-M32       | Code Page                                 | H0HL15D | J0HL14S        | APS450 |
| 5655-M32       | Code Page                                 | H0HL141 | J0HL143        | APS450 |
| 5655-M32       | Code Page                                 | H0HL141 | H0HL141        | APS450 |
| 5655-M32       | ACIF                                      | HQN4450 | HQN4450        | APS450 |
| 5655-M32       | AFP Download Plus                         | HPRF450 | JPRF451        | APS450 |
| 5698-SA3       | IBM AUTOMATION CONTROL FOR Z/OS - TEP     | HKAH35T | HKAH35T        | AUT350 |
| 5698-SA3       | SA z/OS I/O Operations                    | HWRE35D | HWRE35D        | AUT350 |
| 5698-SA3       | SA z/OS Base Automation                   | HWRE350 | HWRE350        | AUT350 |
| 5698-SA3       | SA z/OS CICS AUTO                         | HWRE350 | JWRE35C        | AUT350 |
| 5698-SA3       | SA z/OS UNIQUE                            | HWRE350 | JWRE35F        | AUT350 |
| 5698-SA3       | SA z/OS IMS AUTO                          | HWRE350 | JWRE35I        | AUT350 |
| 5655-103       | DITTO/ESA base                            | H0GB310 | H0GB310        | DIT130 |
| 5655-R29       | IBM Rational COBOL Runtime                | HACZ601 | HACZ601        | ELA601 |
| 5655-Q10       | Debug Tool Base                           | HADRD10 | HADRD10        | EQAD10 |
| 5695-013       | IBM Compiler for REXX on zSeries          | HWK0140 | HWK0140        | FAN140 |
| 5695-014       | IBM Library for REXX on zSeries           | HWJ9140 | HWJ9140        | FAN140 |
| 5695-014       | IBM Alternate Library for REXX on zSeries | HWJ9143 | HWJ9143        | FAN140 |
| 5724-T07       | Rational Developer for z Systems          | HHOP951 | HHOP951        | FEL951 |

|          |   |         |         |        |
|----------|---|---------|---------|--------|
| 5724-T07 | Rational Developer for z Systems Host Utilities | HAKG951 | HAKG951 | FEL951 |
| 5655-EXP | IBM Explorer for z/OS V3.0.0                    | HALG300 | HALG300 | FEL951 |
| 5655-Q10 | PDTCC   | HVWR170 | HVWR170 | FMND10 |
| 5655-Q12 | FILE MANAGER Z/OS BASE                          | HADLD10 | HADLD10 | FMND10 |
| 5655-Q12 | FILE MANAGER Z/OS CICS                          | HADLD10 | JADLD16 | FMND10 |
| 5655-Q12 | FILE MANAGER Z/OS DB2                           | HADLD10 | JADLD12 | FMND10 |
| 5655-Q12 | FILE MANAGER Z/OS IMS                           | HADLD10 | JADLD14 | FMND10 |
| 5655-M23 | IBM HTTP Server                                 | HHAP85P | HHAP85P | HAP850 |
| 5655-Q11 | FAULT ANALYZER/ BASE                            | HADQD10 | HADQD10 | IDID10 |
| 5655-W67 | IBM Enterprise PL/I for z/OS                    | H270450 | H270450 | IEL450 |
| 5655-W67 | IBM Enterprise PL/I for z/OS FEATURE            | H270450 | J270451 | IEL450 |
| 5655-W32 | IBM COBOL FOR Z/OS BASE                         | HADB520 | HADB520 | IGY520 |
| 5655-W32 | IBM COBOL FOR Z/OS HFS                          | HADB520 | JADB52H | IGY520 |
| 5655-W32 | IBM COBOL FOR Z/OS US ENGLISH                   | HADB520 | JADB521 | IGY520 |
| 5635-ISP | IBM DATA SET COMMANDER FOR Z/OS                 | HIQI810 | HIQI810 | IQI810 |
| 5655-J51 | XML Toolkit for z/OS                            | HXML1A0 | HXML1A0 | IXM110 |
| 5655-DGG | IBM 31-Bit SDK for z/OS Java Technology Edition | HJVA800 | HJVA800 | JVA800 |
| 5655-W43 | IBM 31-Bit SDK for z/OS Java Technology Edition | HJVA710 | HJVA710 | JVA710 |

|          |  |         |         |        |
|----------|--|---------|---------|--------|
| 5655-DGH | IBM 64-Bit SDK<br>for z/OS Java<br>Technology<br>Edition             | HJVB800 | HJVB800 | JVB800 |
| 5655-W44 | IBM 64-Bit SDK<br>for z/OS Java<br>Technology<br>Edition             | HJVB710 | HJVB710 | JVB710 |
| 5697-NV6 | IBM<br>AUTOMATION<br>CONTROL FOR<br>z/OS                             | HNVL12B | HNVL12B | NET621 |
| 5697-NV6 | IBM Tivoli<br>NetView Full<br>Version                                | HNV621B | HNV621B | NET621 |
| 5697-NV6 | IBM<br>AUTOMATION<br>CONTROL FOR<br>z/OS English                     | HNVL12B | JNVL12E | NET621 |
| 5697-NV6 | IBM Tivoli<br>NetView English  | HNV621B | JNV621E | NET621 |
| 5655-Y20 | CICS Transaction<br>Gateway for<br>z/OS                              | HCTG910 | HCTG910 | CTG910 |
| 5655-Y24 | CICS VSAM<br>RECOVERY FOR<br>Z/OS V5.1.0                             | HCCV510 | HCCV510 | DWW510 |
| 5655-Y24 | CICS VSAM<br>RECOVERY FOR<br>Z/OS V5.1.0                             | HCCV510 | JCCV51E | DWW510 |
| 5655-Y24 | CICS VSAM<br>Transparency for<br>z/OS - Base                         | HCCV520 | HCCV520 | DWW520 |
| 5655-Y24 | CICS VSAM<br>Transparency for<br>z/OS - English                      | HCCV520 | JCCV52E | DWW520 |
| 5724-V04 | RATIONAL<br>BUILD AGENT<br>for z/OS                                  | HRBA601 | HRBA601 | BLZ601 |
| 5724-V04 | RATIONAL<br>TEAM<br>CONCERT -<br>BUILD SYSTEM<br>TOOLKIT for<br>z/OS | HRBT601 | HRBT601 | BLZ601 |
| 5724-V04 | RATIONAL<br>COMMON<br>COMPONENTS                                     | HRCC601 | HRCC601 | BLZ601 |
| 5724-V04 | RATIONAL<br>TEAM<br>CONCERT -<br>RATIONAL<br>DEVELOPER<br>SUBSET     | HRDV601 | HRDV601 | BLZ601 |



|          |   |         |         |        |
|----------|---|---------|---------|--------|
| 5668-806 | VS FORTRAN<br>LIBRARY MVS                                   | HFL2602 | HFL2602 | AFF260 |
| 5668-806 | MVS IAD   | HFR2602 | HFR2602 | AFF260 |
| 5668-806 | COMPILER<br>MVS   | HFT2602 | HFT2602 | AFF260 |
| 5668-806 | LIBRARY MVS<br>DEP MODULES                                  | HFL2602 | JFL2611 | AFF260 |
| 5668-806 | MVS IAD (TSO)   | HFR2602 | JFR2611 | AFF260 |
| 5668-806 | MVS IAD (ISPF)  | HFR2602 | JFR2620 | AFF260 |
| 5668-806 | COMPILER<br>MVS DEP<br>MODULES                              | HFT2602 | JFT2611 | AFF260 |
| 5668-806 | PUBS POST<br>SCRIPT   | HFT2602 | JFT2612 | AFF260 |
| 5668-806 | PUBS BOOK<br>MANAGER  | HFT2602 | JFT2613 | AFF260 |
| 5655-Y22 | CICS<br>Interdependency<br>Analyzer for<br>z/OS - Base      | H274530 | H274530 | CIU530 |
| 5655-Y22 | CICS<br>Interdependency<br>Analyzer for<br>z/OS - English   | H274530 | J27453E | CIU530 |
| 5655-Y29 | CICS<br>Deployment<br>Assistant                             | HGEM530 | HGEM530 | CPH530 |
| 5725-M54 | UrbanCode<br>Deploy for z/OS<br>6.2.0                       | HRUC620 | HRUC620 | BUZ620 |
| 5655-CEE | IBM z/OS<br>Connect<br>Enterprise<br>Edition V2.0           | HZCN200 | HZCN200 | BAQ200 |
| 5655-X09 | IBM Sterling<br>Connect Direct<br>for z/OS                  | HDGA520 | HDGA520 | DGA520 |
| 5655-X09 | IBM Sterling<br>Connect Direct<br>for z/OS<br>Standard Edit | HDGA520 | JDGA520 | DGA520 |

### CICS V5.3

Describes the CICS v5.3 features shipped with the z/OS v2.2 ADCD.

| Product Number | Description             | Fmid    | Dependent<br>FMID | HLQ    |
|----------------|-------------------------|---------|-------------------|--------|
| 5655-Y04       | CICS - C feature        | HCI7000 | JCI7003           | DFH530 |
| 5655-Y04       | CICS - COBOL<br>feature | HCI7000 | JCI7001           | DFH530 |

|          |  |         |         |        |
|----------|--|---------|---------|--------|
| 5655-Y04 | CICS - PL/1 feature                                | HCI7000 | JCI7002 | DFH530 |
| 5655-Y04 | CICS REXX Development System                       | H0B7110 | H0B7110 | DFH530 |
| 5655-Y04 | CICS REXX Common for CICS/ESA                      | H0Z2110 | H0Z2110 | DFH530 |
| 5655-Y04 | CICS TS Licence                                    | HCTS530 | HCTS530 | DFH530 |
| 5655-Y04 | CICS - JAVA  | HCI7000 | JCI700D | DFH530 |
| 5655-Y04 | CICS - WAS Liberty Profile                         | HCI7000 | JCI700L | DFH530 |
| 5655-Y04 | CICS REXX Runtime Facility                         | H0B5110 | H0B5110 | DFH530 |
| 5655-Y04 | CICS Service Flow Feature for CICS/TS              | HCIZ300 | HCIZ300 | DFH530 |
| 5655-Y04 | CICS - System Manager                              | HCI7000 | JCI700M | DFH530 |
| 5655-Y04 | CICS - WS Security                                 | HCI7000 | JCI700W | DFH530 |
| 5655-Y04 | CICS - Base  | HCI7000 | HCI7000 | DFH530 |
| 5655-Y50 | CICS Transaction Server Feature Pack for Modern Ba | HCIF51B | HCIF51B | DFH530 |
| 5655-Y47 | CICS Transaction Server Feature Pack for Dynamic S | HCIF51D | HCIF51D | DFH530 |
| 5655-Y49 | CICS TS Feature Pack for Security Token Extensions | HCIF51A | HCIF51A | DFH530 |
| 5655-Y48 | CICS Transaction Server Feature Pack for Mobile Ex | HCIF51C | HCIF51C | DFH530 |

## CICS V5.2

Describes the CICS v5.2 features shipped with the z/OS v2.2 ADCD.

| Product Number | Description          | Fmid    | Dependent FMID | HLQ    |
|----------------|----------------------|---------|----------------|--------|
| 5655-Y04       | CICS - C feature     | HCI6900 | JCI6903        | DFH520 |
| 5655-Y04       | CICS - COBOL feature | HCI6900 | JCI6901        | DFH520 |
| 5655-Y04       | CICS - PL/1 feature  | HCI6900 | JCI6902        | DFH520 |

|          |  |         |         |        |
|----------|--|---------|---------|--------|
| 5655-Y04 | CICS REXX Development System                       | H0B7110 | H0B7110 | DFH520 |
| 5655-Y04 | CICS REXX Common for CICS/ESA                      | H0Z2110 | H0Z2110 | DFH520 |
| 5655-Y04 | CICS TS Licence                                    | HCTS520 | HCTS520 | DFH520 |
| 5655-Y04 | CICS - JAVA  | HCI6900 | JCI690D | DFH520 |
| 5655-Y04 | CICS - WAS Liberty Profile                         | HCI6900 | JCI690L | DFH520 |
| 5655-Y04 | CICS REXX Runtime Facility                         | H0B5110 | H0B5110 | DFH520 |
| 5655-Y04 | CICS Service Flow Feature for CICS/TS              | HCIZ300 | HCIZ300 | DFH520 |
| 5655-Y04 | CICS - System Manager                              | HCI6900 | JCI690M | DFH520 |
| 5655-Y04 | CICS - WS Security                                 | HCI6900 | JCI690W | DFH520 |
| 5655-Y04 | CICS - Base  | HCI6900 | HCI6900 | DFH520 |
| 5655-Y50 | CICS Transaction Server Feature Pack for Modern Ba | HCIF51B | HCIF51B | DFH520 |
| 5655-Y47 | CICS Transaction Server Feature Pack for Dynamic S | HCIF51D | HCIF51D | DFH520 |
| 5655-Y49 | CICS TS Feature Pack for Security Token Extensions | HCIF51A | HCIF51A | DFH520 |
| 5655-Y48 | CICS Transaction Server Feature Pack for Mobile Ex | HCIF51C | HCIF51C | DFH520 |

## CICS V5.1

Describes the CICS v5.1 features shipped with the z/OS v2.2 ADCD.

| Product Number | Description                | Fmid    | Dependent FMID | HLQ    |
|----------------|----------------------------|---------|----------------|--------|
| 5655-Y04       | CICS - PL/1 feature        | HCI6800 | JCI6802        | DFH510 |
| 5655-Y04       | CICS - C feature           | HCI6800 | JCI6803        | DFH510 |
| 5655-Y04       | CICS - WS Security         | HCI6800 | JCI680W        | DFH510 |
| 5655-Y04       | CICS - COBOL feature       | HCI6800 | JCI6801        | DFH510 |
| 5655-Y04       | CICS REXX Runtime Facility | H0B5110 | H0B5110        | DFH510 |

|          |   |         |         |        |
|----------|---|---------|---------|--------|
| 5655-Y04 | CICS REXX<br>Common for<br>CICS/ESA                         | H0Z2110 | H0Z2110 | DFH510 |
| 5655-Y04 | CICS - JAVA   | HCI6800 | JCI680D | DFH510 |
| 5655-Y04 | CICS REXX<br>Development<br>System                          | H0B7110 | H0B7110 | DFH510 |
| 5655-Y04 | CICS Service<br>Flow Feature for<br>CICS/TS 3.2             | HCIZ300 | HCIZ300 | DFH510 |
| 5655-Y04 | CICS - WAS<br>Liberty Profile                               | HCI6800 | JCI680L | DFH510 |
| 5655-Y04 | CICS - System<br>Manager                                    | HCI6800 | JCI680M | DFH510 |
| 5655-Y04 | CICS - Base   | HCI6800 | HCI6800 | DFH510 |
| 5655-Y50 | CICS Transaction<br>Server Feature<br>Pack for Modern<br>Ba | HCIF51B | HCIF51B | DFH510 |
| 5655-Y47 | CICS Transaction<br>Server Feature<br>Pack for<br>Dynamic S | HCIF51D | HCIF51D | DFH510 |
| 5655-Y49 | CICS TS Feature<br>Pack for Security<br>Token<br>Extensions | HCIF51A | HCIF51A | DFH510 |
| 5655-Y48 | CICS Transaction<br>Server Feature<br>Pack for Mobile<br>Ex | HCIF51C | HCIF51C | DFH510 |

## DB2 V11

Describes the DB2 v11 features shipped with the z/OS v2.2 ADCD.

| Product Number | Description                          | Fmid    | Dependent<br>FMID | HLQ    |
|----------------|--------------------------------------|---------|-------------------|--------|
| 5655-W87       | IBM DB2<br>UTILITY SUITE<br>FOR Z/OS | HDBBB10 | JDBBB1K           | DSNB10 |
| 5615-DB2       | DB2 JDBC/SQLJ<br>Z/OS                | HDBBB10 | JDBBB12           | DSNB10 |
| 5615-DB2       | DB2 ENGLISH<br>Z/OS                  | HDBBB10 | JDBBB14           | DSNB10 |
| 5615-DB2       | DB2 ODBC<br>Z/OS                     | HDBBB10 | JDBBB17           | DSNB10 |
| 5615-DB2       | DB2 BASE Z/OS                        | HDBBB10 | HDBBB10           | DSNB10 |
| 5697-Q04       | DB2 SPATIAL<br>SUPPORT               | H2AF310 | J2AG310           | DSNB10 |

|          |   |         |         |        |
|----------|---|---------|---------|--------|
| 5697-Q04 | JSON capabilities for DB2 for z/OS            | H2AF310 | J2AS220 | DSNB10 |
| 5615-DB2 | DB2 RACF EXIT Z/OS                            | HDREB10 | HDREB10 | DSNB10 |
| 5615-DB2 | IRLM  | HIR2230 | HIR2230 | DSNB10 |
| 5615-DB2 | DB2 IMS ATTACH Z/OS                           | HIYBB10 | HIYBB10 | DSNB10 |
| 5615-DB2 | DB2 SUBSYS INIT Z/OS                          | HIZBB10 | HIZBB10 | DSNB10 |
| 5697-Q04 | DB2 INT COMP UNICODE                          | H2AF310 | H2AF310 | DSNB10 |
| 5697-Q04 | DB2 Adapter for z/OS Connect                  | H2AZ330 | H2AZ330 | DSNB10 |
| 5655-DAT | IBM DB2 Administration tool for z/OS          | H0IHB10 | H0IHB10 | ADBB10 |
| 5655-DOC | IBM DB2 Object Comparison Tool for z/OS       | H25GB10 | H25GB10 | ADBB10 |
| 5615-DB2 | QMF™ CLASSIC EDITION - ENGLISH                | HSQBB10 | HSQBB10 | QMFB10 |
| 5615-DB2 | Z/OS APPLICATION CONNECTIVITY TO DB2 FOR Z/OS | HDDA211 | HDDA211 | DDA211 |

## DB2 V10

Describes the DB2 v10 features shipped with the z/OS v2.2 ADCD.

| Product Number | Description                        | Fmid    | Dependent FMID | HLQ    |
|----------------|------------------------------------|---------|----------------|--------|
| 5697-Q04       | DB2 SPATIAL SUPPORT                | H2AF210 | J2AG210        | DSNA10 |
| 5697-Q04       | JSON capabilities for DB2 for z/OS | H2AF210 | J2AS120        | DSNA10 |
| 5697-Q04       | DB2 INT COMP UNICODE               | H2AF210 | H2AF210        | DSNA10 |
| 5655-V41       | DB2 UTILITIES SUITE                | HDBAA10 | JDBAA1K        | DSNA10 |
| 5605-DB2       | DB2 BASE Z/OS                      | HDBAA10 | HDBAA10        | DSNA10 |
| 5605-DB2       | DB2 ENGLISH Z/OS                   | HDBAA10 | JDBAA14        | DSNA10 |
| 5605-DB2       | DB2 ODBC Z/OS                      | HDBAA10 | JDBAA17        | DSNA10 |
| 5605-DB2       | DB2 KANJI PANELS - JPN             | HDBAA10 | JDBAA11        | DSNA10 |

|          |  |         |         |        |
|----------|--|---------|---------|--------|
| 5605-DB2 | DB2 JDBC/SQLJ<br>Z/OS                      | HDBAA10 | JDBAA12 | DSNA10 |
| 5605-DB2 | DB2 RACF EXIT<br>Z/OS                      | HDREA10 | HDREA10 | DSNA10 |
| 5605-DB2 | IRLM                                       | HIR2230 | HIR2230 | DSNA10 |
| 5605-DB2 | DB2 IMS<br>ATTACH Z/OS                     | HIYAA10 | HIYAA10 | DSNA10 |
| 5605-DB2 | DB2 SUBSYS<br>INIT Z/OS                    | HIZAA10 | HIZAA10 | DSNA10 |
| 5605-DB2 | QUERY<br>MANAGEMENT<br>FACILITY<br>ENGLISH | HSQAA10 | HSQAA10 | QMFA10 |

### IMS 14.1

Describes the IMS v14.1 features shipped with the z/OS v2.2 ADCD.

| Product Number | Description                       | Fmid    | Dependent<br>FMID | HLQ    |
|----------------|-----------------------------------|---------|-------------------|--------|
| 5635-A05       | IMS                               | HMK1400 | HMK1400           | DFSE10 |
| 5635-A05       | IMS JAVA ON<br>DEMAND<br>FEATURES | HMK1400 | JMK1406           | DFSE10 |
| 5635-A05       | IMS DATABASE<br>MANAGER           | HMK1400 | JMK1401           | DFSE10 |
| 5635-A05       | IMS DLT                           | HMK1400 | JMK1405           | DFSE10 |
| 5635-A05       | IMS EXT.<br>TERMINAL OPT          | HMK1400 | JMK1403           | DFSE10 |
| 5635-A05       | IMS RLT                           | HMK1400 | JMK1404           | DFSE10 |
| 5635-A05       | IRLM                              | HIR2230 | HIR2230           | DFSE10 |
| 5635-A05       | IMS<br>TRANSACTION<br>MANAGER     | HMK1400 | JMK1402           | DFSE10 |

### IMS 13.1

Describes the IMS v13.1 features shipped with the z/OS v2.2 ADCD.

| Product Number | Description                       | Fmid    | Dependent<br>FMID | HLQ    |
|----------------|-----------------------------------|---------|-------------------|--------|
| 5635-A04       | IMS                               | HMK1300 | HMK1300           | DFSD10 |
| 5635-A04       | IMS JAVA ON<br>DEMAND<br>FEATURES | HMK1300 | JMK1306           | DFSD10 |
| 5635-A04       | IMS DATABASE<br>MANAGER           | HMK1300 | JMK1301           | DFSD10 |
| 5635-A04       | IMS DLT                           | HMK1300 | JMK1305           | DFSD10 |
| 5635-A04       | IMS EXT.<br>TERMINAL OPT          | HMK1300 | JMK1303           | DFSD10 |
| 5635-A04       | IMS RLT                           | HMK1300 | JMK1304           | DFSD10 |

|          |                               |         |         |        |
|----------|-------------------------------|---------|---------|--------|
| 5635-A04 | IRLM                          | HIR2230 | HIR2230 | DFSD10 |
| 5635-A04 | IMS<br>TRANSACTION<br>MANAGER | HMK1300 | JMK1302 | DFSD10 |

## IMS Utilities

Describes the IMS utilities shipped with the z/OS v2.2 ADCD.

| Product Number | Description  | Fmid    | Dependent FMID | HLQ    |
|----------------|--|---------|----------------|--------|
| 5655-TDA       | IMS<br>ENTERPRISE<br>SUITE BASE<br>SERVICES                | HAHF320 | HAHF320        | AEW320 |
| 5655-TDA       | IMS<br>ENTERPRISE<br>SUITE MOBILE<br>GATEWAY<br>COMPONENT  | HAHF320 | JAHF32A        | AEW320 |
| 5655-TDA       | IMS<br>ENTERPRISE<br>SUITE IMS<br>SOAP<br>GATEWAY          | HAHF320 | JAHF321        | AEW320 |
| 5655-TDA       | IMS<br>ENTERPRISE<br>SUITE JAVA<br>MESSAGE<br>SERVICES API | HAHF320 | JAHF322        | AEW320 |
| 5655-TDA       | IMS<br>ENTERPRISE<br>SUITE<br>CONNECT API<br>FOR C/JAVA    | HAHF320 | JAHF323        | AEW320 |

## WebSphere Application Server V8.5

Lists information about the WebSphere Application Server v8.5 available with this z/OS 2.2 ADCD.

| Product Number | Description  | Fmid    | Dependent FMID | HLQ    |
|----------------|--|---------|----------------|--------|
| 5655-W65       | WebSphere<br>Application<br>Server for z/OS        | HBBO850 | HBBO850        | WAS850 |
| 5655-W65       | IBM WebSphere<br>SDK Java<br>Technology<br>Edition | HBJA700 | HBJA700        | WAS850 |

## WebSphere Application Server V8.0.0

Lists information about the WebSphere Application Server V8.0.0 available with this z/OS 2.2 ADCD.

| Product Number | Description                           | Fmid    | Dependent FMID | HLQ    |
|----------------|---------------------------------------|---------|----------------|--------|
| 5655-W65       | WebSphere Application Server for z/OS | HBBO800 | HBBO800        | WAS800 |

### **Tivoli OMEGAMON XE for DB2 Performance Expert on z/OS 5.3.0**

Lists the Tivoli OMEGAMON XE for DB2 Performance Expert on z/OS 5.3.0 features available in thews z/OS 2.2 ADCD.

| Product Number | Description  | Fmid    | Dependent FMID | HLQ    |
|----------------|--|---------|----------------|--------|
| 5698-AA8       | ITCAM for Application Diagnostics Common Services  | HAAD71C | HAAD71C        | KAN530 |
| 5698-AA8       | IBM InfoSphere® Optim™ Data Tools Runtime Client   | HPMZ520 | HPMZ520        | KAN530 |
| 5698-AA8       | OMEGAMON XE for WebSphere MQ Configuration         | HKMC730 | HKMC730        | KAN530 |
| 5698-AA8       | OMEGAMON XE for WebSphere MQ Monitoring            | HKMQ730 | HKMQ730        | KAN530 |
| 5698-AA8       | OMEGAMON XE for DB2 on z/OS                        | HKDB520 | HKDB520        | KAN530 |
| 5698-AA8       | OMEGAMON XE for WebSphere Message Broker Monitorin | HKQI730 | HKQI730        | KAN530 |
| 5698-AA8       | End-to-End   | HKET620 | HKET620        | KAN530 |
| 5698-AA8       | OMNIMON Base                                       | HKOB730 | HKOB730        | KAN530 |
| 5698-AA8       | OMEGAMON XE for CICS TG on z/OS                    | HKGW530 | HKGW530        | KAN530 |
| 5698-AA8       | OMEGAMON XE for CICS on z/OS                       | HKC5530 | HKC5530        | KAN530 |
| 5698-AA8       | ITCAM for Application Diagnostics, TEMA            | HKYN710 | HKYN710        | KAN530 |
| 5698-AA8       | OMEGAMON XE for IMS on z/OS                        | HKI5510 | HKI5510        | KAN530 |



|          |   |         |         |        |
|----------|---|---------|---------|--------|
| 5698-AA8 | OMEGAMON<br>XE for DB2<br>Performance<br>Expert on z/OS | HKDB52X | HKDB52X | KAN530 |
| 5698-AA8 | ITCAM for<br>Application<br>Diagnostics                 | HAAD710 | HAAD710 | KAN530 |
| 5698-AA8 | Generic<br>Configuration                                | HKCF730 | HKCF730 | KAN530 |
| 5698-A79 | Installation/<br>Configuration<br>Assistance Tool       | HKCI310 | HKCI310 | KAN530 |
| 5698-A79 | TMS:Engine  | HKLV630 | HKLV630 | KAN530 |
| 5698-A79 | Tivoli Enterprise<br>Monitoring<br>Server               | HKDS630 | HKDS630 | KAN530 |

## Reported problems, fixes, and maintenance

See the reported problems, fixes, and maintenance available in this ADCD.

- Problem: DLIB data sets not cataloged in May 2016 Release.

The data sets on the DLIB volumes in the May 2016 release of ADCD were not cataloged. This issue is important to users who want to do maintenance on the ADCD. To catalog the data sets on the DLIB volumes, you must download two files. The INPUT file is in format RECFM=FB, which was compressed with TRSMMAIN.

Binary download the INPUT file by right-clicking on the link and storing the file on your PC. Be sure to give the file a meaningful name so you can find it to binary upload it or process it.

To restore the RECFM=FB data set, binary upload it to a z/OS system. The data set built from the upload must have a RECFM=FB and LRECL=1024. The BLKSIZE does not matter. Since the data sets were compressed with TRSMMAIN, use TRSMMAIN to decompress and rebuild the original data set from the uploaded data set. Rebuild the original data set from the uploaded data set. Review more information about TRSMMAIN.

Download the RECFM=FB maintenance file compressed with TRSMMAIN

The downloaded file is approximately 4 KB.

The compressed file requires (15) 3390 tracks.

The following text file is sample JCL to assist with cataloging the data sets.

CATJCL - Select then copy and paste the text to a meaningful data set.

- To enable EAV on the ADCD system dynamically, enter this command:  
SETSMS USEEAV(YES). To make the change take effect across IPLs, update the IGDSMSxx member in PARMLIB to add the USEEAV(yes) value and IPL.

## Build structure

Describes the build structure of the volumes shipped with the z/OS v2.2 ADCD.

### B2RES1 and B2RES2

B2RES1 is a 3390-9 volume that contains the base MVS system software target, or run-time libraries, and other system data sets required to IPL the system and use TSO/E and ISPF. It is the MVS IPL volume.

B2RES2 is a 3390-9 volumes that are an extension of the SYSRES volume B2RES1. The volume is also required for IPL.

#### **B2SYS1**

This 3390-9 volume contains data sets that you might change, either through normal use of the system or user customization. System control data sets, such as SYS1.IPLPARM,IODF (I/O Definition File), and system's master catalog (CATALOG.Z22B.MASTER) are on this volume. This volume is required to IPL. B2SYS1 contains the user catalog USERCAT.Z22B.PRODS containing entries for z/OS related products.

#### **B2CFG1**

This 3390-9 volume contains data sets for storing user configuration. The 'USER.\*\*' data sets are on this volume, they are cataloged in the master catalog. The RACF database is on this volume.

#### **B2USS1 and B2USS2**

B2USS1 is a 3390-9 volume that contains the Fonts, Version, and zOSMF zFS files for UNIX System Services of z/OS. This volume is required to IPL.

B2USS2 is a 3390-9 volume that contains root zFS and zFS files for UNIX System Services of z/OS. This volume is required to IPL.

#### **B2PRD1, B2PRD2 and B2PRD3**

B2PRD1 to B2PRD3 are 3390-9 volumes that contain all z/OS products.

#### **B2DIS1 and B2DIS2**

These volumes contain the base MVS system software distribution libraries. They contain the DLIB (Distribution Library) and zone CSIs. These volumes are needed to install service or products on the MVS system by using SMP/E. These volumes are all 3390-9.

#### **B2PAGA, B2PAGB and B2PAGC**

These volumes contain page data sets. The B2PAGA volume has the PLPA, Common and one Local page data set. Rest of the 2 volumes each have one Local page data set. The loadparms that bring up DB2 or WAS have been defined to use all the above 3 page volumes, all other loadparms use only the first two volumes. If you do not want to use all of these local page data sets, you can modify the PAGE parameter on IEASYSnn member, accordingly.

#### **B2DBB1, B2DBB2 and B2DBAR**

B2DBB1 is a 3390-9 volume that contains DB2 V11 related data. B2DBB1 contains the DB2 usercatlog, USERCAT.Z22B.DB2VB. Also B2DBB1 contains all DB2 target libs AND DB2 V11 utility products. This volume is not required to IPL but is required to bring up DB2 V11.

B2DBB2 is a 3390-9 volume that contains DB2 catalog and directories with HLQ DSNCB10, which are SMS managed. The volume is not required for IPL but is needed to bring up DB2.

B2DBAR is a 3390-9 volume defined in a new esoteric called DBARCH. This esoteric has been defined in DB2, for allocating the archive logs into this storage volume. This volume is required, if you want to bring up DB2 V11.

#### **B2DBA1, B2DBA2 and B2DBAR**

B2DBA1 is a 3390-9 volume that contains DB2 V10 related data. B2DBA1 contains the DB2 usercatlog, USERCAT.Z22B.DB2VA. Also B2DBA1 contains all DB2 target libs and DB2 V10 utility products. This volume is not required to IPL but is required to bring up DB2 V10.

B2DBA2 is a 3390-9 volume that contains DB2 catalog and directories with HLQ DSNCA10, which are SMS managed. The volume is not required for IPL but is needed to bring up DB2.

B2DBAR is a 3390-9 volume defined in a new esoteric called DBARCH. This esoteric has been defined in DB2, for allocating the archive logs into this storage volume. This volume is required, if you want to bring up DB2 V10.

#### **B2C531**

B2C531 is a 3390-9 volume that contains CICS 5.3 Target, DLIB and all related data for CICS 5.3. USERCAT.Z22B.CICS530 is on this volume. This volume is not required to IPL but is required to bring up CICS 5.3 and apply CICS maintenance.

#### **B2C521**

B2C521 is a 3390-9 volume that contains CICS 5.2 Target, DLIB and all related data for CICS 5.2. USERCAT.Z22B.CICS520 is on this volume. This volume is not required to IPL but is required to bring up CICS 5.2 and apply CICS maintenance.

#### **B2C511**

B2C511 is a 3390-9 volume that contains CICS 5.1 Target, DLIB and all related data for CICS 5.1. USERCAT.Z22B.CICS510 is on this volume. This volume is not required to IPL but is required to bring up CICS 5.1 and apply CICS maintenance.

#### **B2W851, B2W852, B2W853, B2W854, B2W855, B2W856 and B2W857**

B2W851, B2W852 and B2W853 are 3390-9 10000 cyls volume that contains target and distribution libraries for Websphere Application Services.

B2W855 to B2W857 are 3390-9 volumes that contain pre-configured zFS files required for manually starting WAS.

#### **B2W801, B2W802, B2W803, B2W804 and B2W805**

B2W801, B2W802 and B2W803 are 3390-9 10000 cyls volume that contains target and distribution libraries for Websphere Application Services.

B2W804 and B2W805 are 3390-9 volumes that contain pre-configured zFS files required for manually starting WAS.

#### **B2IME1, B2IMD1, B2IMC1, B2IMU1 and B2IMU2**

B2IME1 is a 3390-9 volume that contains IMS Target, DLIB and all related data for IMS 14. USERCAT.Z22B.IMS14 is on this volume. This volume is not required to IPL but is required to bring up IMS and perform maintenance on IMS.

B2IMD1 is a 3390-9 volume that contains IMS Target, DLIB and all related data for IMS 13. USERCAT.Z22B.IMS13 is on this volume. This volume is not required to IPL but is required to bring up IMS and perform maintenance on IMS.

B2IMC1 is a 3390-9 volume that contains IMS Target, DLIB and all related data for IMS 12. USERCAT.Z22B.IMS12 is on this volume. This volume is not required to IPL but is required to bring up IMS and perform maintenance on IMS.

B2IMU1 and B2IMU2 are 3390-9 10000 cylinder volumes that contain IMS Utilities. These volumes are not required to IPL but is required for IMS Utilities and perform maintenance on IMS Enterprise Suite.

#### **B2KAN1**

B2KAN1 is a 3390-9 volume that contains Target and DLIB libraries for Tivoli OMEGAMON XE for DB2 Performance Expert on z/OS 5.3.0. This volume is not required to IPL but is required to bring up Omegamon XE for DB2 PE.

#### **B2BLZ1**

B2BLZ1 is a 3390-9 volume that contains Target and DLIB libraries for Rational Team Concert 6.0.1 This volume is not required to IPL but is required to bring up RTC.

#### **SARES1**

This 3390-3 volume contains a single volume stand alone system. This volume can be used to IPL and logon to a TSO/ISPF session.

The disk volume can assist in building LPAR environments and correct errors that prevent system IPL.

Recommended use of this volume is to install the volume and leave accessible. The volume should not be altered. The volume should stay in a background mode and be available for emergency type of situations. If other z/OS, OS/390®, or LPAR partitions contain errors, the SARES1 volume could be used to solve the problem.

The stand alone system does not contain TCPIP or Unix system service support. The system cannot be used to install products or apply maintenance via SMP/E.

To IPL the standalone res volume:

Load Address: 0Axx

Load Parms: 0AxxSAM

## **Migration Guidelines**

Use these guidelines to replace this level of system software with new levels built the same way.

Ensure that only IBM-supplied system software is on A2xxxx volumes except for B2SYS1. B2SYS1 contains RACF, IPL, and catalog data sets that are user-dependent.

The ADCD does not contain a generalized migration utility or process. Each user has unique requirements. Build a migration plan that suits your unique needs. The ADCD does have some assistance. The ADCD uses a system of concatenated libraries. The highest level of concatenation is USER.xxxxxxxx. The ADCD distributes these libraries empty. Place changes or overrides in these libraries. Also, back up the USER.xxxxxxxx libraries regularly. When a new ADCD release is installed, the USER.xxxxxxxx libraries can be copied from backups to the new USER.xxxxxxxx libraries to help migration of programs and parameters.

The ADCD is distributed with a standard library concatenation for these libraries:

- LINKLST
- PROCLIB (including TSO procedures)
- CLIST
- ISPLLIB (TSO panels)
- LPALIB
- PARMLIB
- VTAMLST
- VTAMLIB
- VTAM source

The configured order of concatenation is user, ADCD developers, and z/OS system data sets. For example, the LINKLST concatenation would be as follows:

- USER.LINKLIB
- ADCD.Z22B.LINKLIB
- SYS1.LINKLIB

USER.xxxxx libraries were built on B2CFG1, which is the only volume that should contain user data.

USER.xxxxx is not changed by ADCD or System processes; thus, user updates in USER.xxxxx are retained between release levels. ADCD.Z22B.xxxxx libraries are allocated on B2SYS1 and are the libraries that are used by ADCD developers. No RACF rules exist on these libraries; however, changes to these libraries might destroy customization necessary to start many products. Never update SYS1.xxxxx libraries by users or ADCD development. Update system libraries only through SMP/E installation, maintenance processes, or like processes.

**Note:** Changes to System libraries or ADCD precustomization might corrupt your system and prevent or delay IBM support activities.

This procedure for a user update to system data is correct:

- Copy the system data from SYS1.xxxxx or ADCD.xxxx to USER.xxxxx
- Edit, compile, or run user program against the USER.xxxx item
- Re-IPL, recycle system service, or relogin to TSO

The correct procedure for removing a user update is the reverse of this procedure.

## LOADPARMS Options

Lists available preconfigured distributed LOADPARMS.

**Note:** Start JES2 cold the first time you start the system.

*Table 1. Listing of available preconfigured distributed LOADPARMS.*

| LOADPARAM | Description   |
|-----------|---|
| CS        | CLPA and Cold start of JES2. Base z/OS system functions, that is, no CICS, DB2, IMS, Websphere Application Server, and so on. |
| WS        | CLPA and Warm start of JES2. Base z/OS system functions, that is, no CICS, DB2, IMS, Websphere Application Server, and so on. |
| 00        | CLPA and Warm start of JES2. Base z/OS system functions, that is, no CICS, DB2, IMS, Websphere Application Server, and so on. |

Table 1. Listing of available preconfigured distributed LOADPARMS. (continued)

| LOADPARM | Description  |
|----------|--|
| CI       | CLPA and Warm start of JES2. Loads CICS 5.3 and 5.2 libraries. Starts CICS 5.3 and Rational Developer for z Systems.   |
| DB       | CLPA and Warm start of JES2. Loads DB2 V11 and V10 libraries. Starts DB2 V11 and Rational Developer for z Systems.   |
| IM       | CLPA and Warm start of JES2. Loads IMS 14 and 13 libraries. up Starts IMS 14 and Rational Developer for z Systems.   |
| IZ       | CLPA and Warm start of JES2. Starts up z/OSMF and Rational Developer for z Systems.  |
| WA       | CLPA and Warm start of JES2. Loads Websphere Application Server 8.5 libraries. Starts Rational Developer for z Systems. Websphere Application Server needs to be manually started. |
| AL       | CLPA and Warm start of JES2. Loads all middleware libraries. Starts CICS 5.3, DB2 V11, IMS 14, z/OSMF and Rational Developer for z Systems.  |
| DC       | CLPA and Cold start of JES2. Loads CICS, DB2 libraries. Starts CICS 5.3, DB2 V11, UCD 6.2.0, RTC 6.0.1, Rational Developer for z Systems and UCD.                                  |
| DW       | CLPA and Warm start of JES2. Loads CICS, DB2 libraries. Starts CICS 5.3, DB2 V11, UCD 6.2.0, RTC 6.0.1, Rational Developer for z Systems and UCD.                                  |

## Console PF Key Settings

Describes the default PF key assignments.

| Action/Command  | PFKey |
|---|-------|
| Display Devices                                       | PF1   |
| Display 3270 Devices                                  | PF2   |
| Clear Top of Screen                                   | PF3   |
| Create a 10-line Display Area                         | PF4   |
| Display Address Space Information                     | PF5   |
| Display Outstanding Reply Requests and Error Messages | PF6   |
| Display PF Keys                                       | PF7   |
| Scroll Display Area                                   | PF8   |
| Display TSO Users                                     | PF9   |
| Display Active Address Spaces                         | PF10  |
| Display Active Jobs                                   | PF11  |
| Clear Bottom Screen                                   | PF12  |

## USERIDS

Lists the TSO User IDs and passwords that are set up on your system.

*Table 2. Predefined USERIDS..* The following TSO User IDs and passwords are set up on your system:

| User ID                                 | Password        |
|---|-----------------|
| ADCDMST (RACF special authority)        | SYS1 or ADCDMST |
| IBMUSER (RACF special authority)        | SYS1 or IBMUSER |
| SYSADM (DB2 and RACF special authority) | SYS1 or SYSADM  |
| SYSOPR (DB2 and RACF special authority) | SYS1 or SYSOPR  |
| ADCD - ADCDZ                            | TEST            |
| WEBADM                                  | WEBADM          |
| OPEN1 through OPEN3                     | SYS1            |
| ZOSMFAD                                 | ZOSMFAD         |

## Maintenance Service Levels

All the products on the ADCD consist of maintenance that is in a closed status. A PTF that is still in open status or has other than a document hold at the time the ADCD was built would not be added to the ADCD. The following PUT levels might be minus PTFs that were open at build time. Also, some functions might be better than the PUT level due to the addition of RSUs and individual PTFs. In general, the following is valid.

- All functions of the base z/OS 2.2 May2016 are at RSU level 160.
- All functions of the CICS TS 5.3 are at RSU level 1602.
- All functions of the CICS TS 5.2 are at RSU level 1602.
- All functions of the CICS TS 5.1 are at RSU level 1602.
- The functions of the DB2 11 base are at RSU level 1602.
- The functions of the DB2 10 base are at RSU level 1602.
- All functions of the IMS 14.1.0 are at RSU level 1602.
- All functions of the IMS 13.1.0 are at RSU level 1602.
- All functions of the IMS 12.1.0 are at RSU level 1602.
- All functions of the IMS Utilities are at PUT level 1601.
- Tivoli OMEGAMON XE for DB2 Performance Expert on z/OS 5.3.0 is at RSU level 1602.

---

## Hints and tips to manage the z/OS 2.2 ADCD

Learn about page data sets available, starting IMS and running an IVP transaction, WLM configuration provided, ACS routines provided, recreating the coupling data sets, allocating DB2 archive logs into an esoteric, steps for dumping SMF data into GDG (Generation Data Group) data sets, using the esoteric devices, and how to start IBM Healthchecker for z/OS, IBM z/OS Management Facility (z/OSMF), and WebSphere Application Server.

## Page data sets

This ADCD system provides you with three volumes that are dedicated for page data sets, B2PAGA through B2PAGC.

This list shows the contents of the volumes.

- B2PAGA
  - SYS1.PLPA.PAGE
  - SYS1.COMMON.PAGE
  - SYS1.LOCALA.PAGE
- B2PAGB SYS1.LOCALB.PAGE
- B2PAGC SYS1.LOCALC.PAGE

The preconfigured loadparms that are meant for starting DB2 and WebSphere Application Server use all of these page data sets. The remaining loadparms use only the data sets on volumes B2PAGA and B2PAGB. You can add or remove these page data sets as needed by using this parameter in the IEASYSxx member after you copy it to USER.PARMLIB.

```
PAGE=(SYS1.PLPA.PAGE,  
      SYS1.COMMON.PAGE,  
      SYS1.LOCALA.PAGE,  
      SYS1.LOCALB.PAGE,L),
```

## Starting IMS and running an IVP transaction

Find information about starting IMS.

The instructions for starting and stopping IMS can be found at [This page has pointers to the levels of IMS V12, V13 and V14. On each level, click \*\*Issues, Hints and Tips\*\* to see the instructions for starting and stopping. The IVP jobs are available on the ADCD system, in the data set DFSE10.INSTALIB for IMS v14, DFSD10.INSTALIB for IMS v13, and IMS1210.INSTALIB for IMS v12. You must run each series in a specific manner to create the particular IVP environment and data to be able to follow each IVP.](http://dtsc.dfw.ibm.com/MVSDS/'HTTPD2.DFSD10.PUBLIC.SHTML(INDEX)'>http://dtsc.dfw.ibm.com/MVSDS/'HTTPD2.DFSD10.PUBLIC.SHTML(INDEX)'</a></p></div><div data-bbox=)

## WLM configuration provided on ADCD z/OS

The WLM configuration of application environments for DB2 Stored Procedures for DBAG are self-documented in the WLM application environment display.

For DBAG (DB2 V10), the comment describes the usage of each environment.

|          |                          |
|----------|--------------------------|
| DBAGENV  | Default                  |
| DBAGENVC | DSNWLM_DSNACICS          |
| DBAGENVD | DSNWLM_DEBUGGER          |
| DBAGENVG | DSNWLM_GENERAL           |
| DBAGENVJ | DSNWLM_JAVA              |
| DBAGENVM | DSNWLM_MQSERIES          |
| DBAGENVO | DSNWLM_JAVA_BIGMEM       |
| DBAGENVP | DSNWLM_PGM_CONTROL       |
| DBAGENVR | DSNWLM_REXX              |
| DBAGENVU | DSNWLM_UTILS             |
| DBAGENVW | DSNWLM_WEBSERVICES       |
| DBAGENVX | DSNWLM_XML               |
| DBAGENV1 | DSNWLM_NUMTCB1           |
| DBAGRFSH | Stored Procedure REFRESH |

For DBBG (DB2 V11), the comment describes the usage of each environment.

|          |                 |
|----------|-----------------|
| DBBGENV  | Default         |
| DBBGENVC | DSNWLM_DSNACICS |
| DBBGENVD | DSNWLM_DEBUGGER |
| DBBGENVG | DSNWLM_GENERAL  |



|          |                          |
|----------|--------------------------|
| DBBGENVJ | DSNWLM_JAVA              |
| DBBGENVM | DSNWLM_MQSERIES          |
| DBBGENVO | DSNWLM_JAVA_BIGMEM       |
| DBBGENVP | DSNWLM_PGM_CONTROL       |
| DBBGENVR | DSNWLM_REXX              |
| DBBGENVU | DSNWLM_UTILS             |
| DBBGENVW | DSNWLM_WEBSERVICES       |
| DBBGENVX | DSNWLM_XML               |
| DBBGENV1 | DSNWLM_NUMTCB1           |
| DBBGRFSH | Stored Procedure REFRESH |

## ACS routines provided on ADCD

DB2 V11 requires that its catalog and directory to be SMS-managed. The ACS routines available on ADCD z/OS system were created to handle HLQ DSNCB10, which is the HLQ of the DB2 V11 Catalog and Directory. The logic is to use two qualifiers, first is DSNCB10, and the second is DSNDBC or DSNDBD. The DSNDBC and DSNDBD indicates the cluster and data portion of the VSAM data set of a DB2 table space. Other data sets for DB2 V11 have a HLQ of DSNB10 and are not SMS-managed. A DB2 STOGROUP called SYSSMS was created for the Catalog and Directory table spaces with a VCAT of DSNCB10 and VOL of (\*). The (\*) is for SMS-managed STOGROUP. The DB2 STOGROUP, SYSDEFLT uses VCAT of DSNB10 and lists actual volumes and is not SMS-managed. The installation is configured to use SYSSMS when it creates the catalog and directory table spaces. If users create and specify a STOGROUP of their own or default to SYSDEFLT STOGROUP, their table spaces fall into non-SMS managed volumes as specified in the STOGROUP.

This information applies for DB2 V10 also, with the corresponding HLQ DSNCA10 being SMS-managed

## Recreating the coupling data sets

These coupling data sets are provided on ADCD.

```

SYS1.ADCDPL.CDS01
SYS1.ADCDPL.CDS02
SYS1.ADCDPL.LOGR.CDS01
SYS1.ADCDPL.LOGR.CDS02
SYS1.ADCDPL.OMVS.CDS01
SYS1.ADCDPL.OMVS.CDS02
SYS1.ADCDPL.WLM.CDS01
SYS1.ADCDPL.WLM.CDS02

```

In case any of these data sets are corrupted or become unusable, delete them and use the JCL in member ALOCCOPL of the ADCD.LIB.JCL data set to allocate them again.

**Note:** This procedure is provided to you, assuming that you have a thorough knowledge of setting up a SYSPLEX environment. These steps are a bit involved and could cause disruption of normal functioning of your ADCD system.

## Allocating DB2 archive logs into an esoteric device

Additional storage volume B2DBAR was defined and is pointed to by a new esoteric DBARCH, for DB2 archive logs. Instructions for adding more volumes to this esoteric are provided here. Map this volume B2DBAR to device# 0AA3 in your devmap so that it is in sync with the IODF definition.

In this edition of ADCD z/OS, the loadparms that are meant to start DB2, have been configured to use the esoteric device DBARCH for holding the DB2 archive logs. The archive logs go only into this volume (or volumes if you add more to the esoteric). You still need to manage the space on the volume and delete archive logs that are no longer needed. The fourth qualifier in the data set name is a date of the format *Dyynnn* where *yy* is the year and *nnn* is the Julian day of the year. When you start DB2, examine the console log to see that it does not read any archive logs. If no archive logs are used at the start, then you have a clean start of DB2 and you can delete all the prior archive logs. If you are running DB2 and run out of space in the esoteric DBARCH volumes, look at the SDSF console log for DB2 and determine the start date. Then, you can delete archive logs before the start date of the last clean start of DB2. Monitor the space available on your DBARCH esoteric volumes. Better space management can be achieved by turning off logging on some of your table spaces that can be recovered by just dropping, re-creating, and reloading. You can also reduce logging by using the LOG NO parm in your load utility job. You must reset the COPY pending flag with the NOCOPYPEND parm in the load utility or the REPAIR utility. Use these options only for table spaces that you can recover on your own without DB2 recovery. A thoughtful management of DB2 archive logs is important in any DB2 environment: test, development, or production.

Also, even though you delete the DSNx10.DBxG.ARCLOG1.Date.Time.A0000000# data sets, you need to keep enough of the DSNx10.DBxG.ARCLOG1.Date.Time.B0000000# data sets to cover two successful restarts of DB2. These data sets are the backups for your BSDS data sets. If anything happens to your BSDS; you need these backups to restore your BSDS.

The DBARCH esoteric is coded into DB2 ZPARM, by way of the link-edit JCL member DSNTIJUZ in DSNx10.NEW.SDSNSAMP. These parameters are coded under the DSN6ARVP section of DSNTIJUZ. This information is provided here, just in case you want to create and update with a different esoteric other than the one provided.

```
TSTAMP=YES, X
UNIT=DBARCH, X
UNIT2=
```

To change an esoteric, you need to update the IODF file. The default active IODF in the ADCD system is SYS1.IODF99. When you try to modify it, a temporary work IODF is created, which can be named however you choose, for example, SYS1.IODF03.WORK. After the changes are made, the work file can be used to create a production IODF file, such as SYS1.IODF03. After you change the loadparm to use SYS1.IODF03, you can re-LPI the system to check that the changes you made are working properly. You can either continue to use SYS1.IODF03 or copy it to SYS1.IODF99. If you choose to copy it to IODF99, you must make a backup of SYS1.IODF99 and then delete SYS1.IODF99. After you delete SYS1.IODF99, copy SYS1.IODF03 to SYS1.IODF99 and update the loadparm member to use SYS1.IODF99.

To add more volumes to the esoteric DBARCH:

1. From the ISPF primary option menu, select option **M.4. Hardware Configuration Tools**.
2. In the **I/O definition file** field, type SYS1.IODF99, and then select option **1. Define, modify, or view configuration data**.

```

Command ==>
Hardware Configuration

Select one of the following.

0. Edit profile options and policies
1. Define, modify, or view configuration data
2. Activate or process configuration data
3. Print or compare configuration data
4. Create or view graphical configuration report
5. Migrate configuration data
6. Maintain I/O definition files
7. Query supported hardware and installed UIMs
8. Getting started with this dialog
9. What's new in this release

For options 1 to 5, specify the name of the IODF to be used.

I/O definition file . . . 'SYS1.IODF99'

```

- On the Define, Modify, or View Configuration Data window, select option 1. Operating system configurations.

```

C Define, Modify, or View Configuration Data
S Select type of objects to define, modify, or view data.
1 1. Operating system configurations
   consoles
   system-defined generics
   EDTs
   esoterics
   user-modified generics
2 2. Switches
   ports
   switch configurations
   port matrix
3 3. Processors
   channel subsystems
   partitions
   channel paths
F 4. Control units
I 5. I/O devices
  6. Discovered new and changed control units and I/O devices

```

- On the Operating System Configuration List, type / to select Config. ID OS390, and then press Enter.

```

-----
Operating System Configuration List Row 1 of 1
Command ==> Scroll ==> PAGE

Select one or more operating system configurations, then press Enter. To
add, use F11.

/ Config. ID Type Gen Description D/R site OS ID
/ OS390 MVS ADCD ZOS IODF
***** Bottom of data *****

```

- On the Actions on selected operating systems window, select option 5. Work with EDTs.

```

-----
Command ==>
Select one or
add, use F11.

/ Config. ID
/ OS390
*****

----- Actions on selected operating systems -----
Select by number or action code and press Enter.

1. Add like . . . . . (a)
2. Repeat (copy) OS configurations . . (r)
3. Change . . . . . (c)
4. Delete . . . . . (d)
5. Work with EDTs . . . . . (s)
6. Work with consoles . . . . . (n)
7. Work with attached devices . . . . (u)
8. View generics by name . . . . . (g)
9. View generics by preference value . (p)

```

6. On the EDT List, type / beside EDT 00, and then press Enter.

```

- Goto Backup Query Help
-----
C Row 1 of 1
Command ==> Scroll ==> PAGE
S
a Select one or more EDTs, then press Enter. To add, use F11.

/ Configuration ID . : OS390 ADCD ZOS IOCF
/
* / EDT Last Update By Description
/ 00 2012-05-17 IBMUSER Add new esoterics
***** Bottom of data *****

```

7. In the Actions on selected EDTs window, select option 4. Work with esoterics.

```

- EDT List
-----
Goto Backup Query Help
-----
C
Command =
S
a Select on

/ Configura
/
* / EDT Las
/ 00 201
*****

----- Actions on selected EDTs -----
Select by number or action code and press Enter.

4 1. Repeat (copy) EDTs . . . . . (r)
2. Change . . . . . (c)
3. Delete . . . . . (d)
4. Work with esoterics . . . . . (s)
5. Work with generics by name . . . . (g)
6. Work with generics by pref. value . (p)

```

8. On the Esoteric List, type / beside Esoteric DBARCH, and then press Enter.

```

-      Goto Filter Backup Query Help
C      -----
S      Command ==>                               Row 1 of 7
a      Scroll ==> PAGE
/      Select one or more esoterics, then press Enter. To add, use F11.
/      Configuration ID . : OS390          ADCD 20S IODF
/      EDT identifier . . : 00            Add new esoterics
*
/ Esoteric VIO Token State
- DASD     Yes  1
/ DBARCH   Yes  3
- SORT     Yes  5
- SYSDA    Yes  7
- TEMP     Yes  9
- VIO      Yes 11
- WORK     Yes 13
***** Bottom of data *****

```

9. On the Actions on selected esoterics list, select option 4. Assign devices.

```

-      Goto Filter Backup Query Help
C      -----
S      Command =
a      Select on
/      4. 1. Repeat (copy) esoterics . . . . . (r)
/      2. Change . . . . . (c)
/      3. Delete . . . . . (d)
*      4. Assign devices . . . . . (s)
/      5. View assigned devices . . . . . (v)
/ Esoteri
- DASD
/ DBARCH
- SYSDA
- VIO      Yes
***** Bottom of data *****

```


10. On the Assign/Unassign Devices to Esoteric window, select the appropriate device or device range that you want to add to the DBARCH esoteric. For example, to add one more device at address 0AA7, type Yes in the **Assigned** column of that row, type 0AA7 in the **Starting Number** column, and type 1 in the **Number of Devices** column. Press Enter.

```


-      Goto Filter Backup Query Help
C      -----
S      Command ==>                               Row 11 of 17
a      Scroll ==> PAGE
/      Specify Yes to assign or No to unassign.
/      Configuration ID . : OS390          ADCD 20S IODF
/      EDT.Esoteric . . . : 00.DBARCH      VIO eligible . : No
*
Devices Device Type Name Assigned Starting Number of
0900,13 3270-X 3277-2 No
090E,18 3270-X 3277-2 No
0A80,38 3390 3390 No
0AA6,1 3390 3390 Yes
0AA7,73 3390 3390 Yes 0AA7 1
OE20,4 CTC CTC No
OE40,4 CTC CTC No
***** Bottom of data *****
To leave the panel press EXIT or CANCEL.

```


11. On the Create Work I/O Definition File window, type a name for the temporary work IODF, for example, SYS1.IODF03.WORK, and then press Enter.




The Assign/Unassigned Devices to Esoteric window is updated to show the list of devices assigned. Because device 0AA6 was already assigned, it is updated to include two devices in that range: 0AA6 and 0AA7.




- In the I/O definition file field of the primary option menu of HCD, type SYS1.IODF03.WORK, and then select option 2. **Activate or process configuration data.**



- In the Activate or Process Configuration Data window, select option 1. **Build production I/O definition file.**



The changes that are made are verified. Any errors or warnings that are displayed at this stage can be ignored.



14. Press F3 to return to the Activate or Process Configuration Data window and select option 1. **Build production I/O definition file.**
15. To create the production I/O definition file:
  - a. In the **Work IODF name** field, type SYS1.IODF03.WORK.
  - b. In the **Production IODF name** field, type SYS1.IODF03.
  - c. In the **Volume serial number** field, specify the volume where IODF99 is.
  - d. In the **Continue using as current IODF:** field, specify option 2. **The new production IODF specified above.**
  - e. Press Enter.

```

C      Activate or Process Configuration Data
S      Build Production I/O Definition File
S 1    Specify the following values, and choose how to continue.
2      Work IODF name . . . : 'SYS1.IODFC3.WORK'
      Production IODF name . 'SYS1.IODFC3'
      Volume serial number . $DSYS1
      Continue using as current IODF:
      2  1. The work IODF in use at present
         2. The new production IODF specified above
F
I * = requires TSR I/O Operations

```

16. In the Define Descriptor Fields window, specify values for descriptor fields 1 and 2, and press Enter.

```

C      Activate or Process Configuration Data
S      Build Production I/O Definition File
S 1    Specify the following values, and choose how to continue.
2      Work IODF name . . . : 'SYS1.IODFC3.WORK'
      Production IODF name . 'SYS1.IODFC3'
      Vo      Define Descriptor Fields
      Co
      2      Specify or revise the following values.
      Production IODF name . : 'SYS1.IODFC3'
      Descriptor field 1 . . : SYS1
      Descriptor field 2 . . : IODFC3
F
I * = re

```

The message Production IODF SYS1.IODFC3 created. is displayed.

17. Exit HCD, and then create a new loadparm member by using LOADCS as a template as shown in this example. To use IODF03, change the IODF parm value 99 - 03.

```

C      Activate or Process Configuration Data
      Select one of the following tasks.
S 1    1. Build production I/O definition file
      2. Build IOCCDS
2      3. Build IOCP input data set
      4. Create JES3 initialization stream data
      5. View active configuration
      6. Activate or verify configuration dynamically
      7. Activate configuration sysplex-wide
      8. *Activate switch configuration
      9. *Save switch configuration
      10. Build I/O configuration data
      11. Build and manage S/390 microprocessor IOCCDSs and IPL attributes
F      12. Build validated work I/O definition file
I * = requires TSR I/O Operations
      Production IODF SYS1.IODFC3 created.

```

18. IPL the system with loadparm 01 to ensure that IODF03 works without error. If you want to continue using IODF03, modify other loadparms as required. Otherwise, if you want to copy the changes to IODF99, take back up IODF99 by using option 6. **Maintain I/O definition files**, and then option 2. **Copy I/O definition file**. Then, delete file IODF99 and repeat options 6 and 2 to copy IODF03 into IODF99.



## Steps for dumping SMF data into GDG data sets

The system is configured to clear SMF data by using the procedure SMFCLEAR. This procedure is triggered by the exit routine IEFU29, the source code of which is available in ADCD.LIB.JCL. If you want to save the SMF data into GDG data sets, modify this exit routine to call procedure SMFDUMPS. Edit exit routine IEFU29 to change occurrences of string SMFCLEAR to SMFDUMPS and assemble and link edit the load module by using the JCL member IEFU29@, which is also available in ADCD.LIB.JCL. IPL the system so that this change takes effect. A GDG base SYS1.SMF.DATA was defined by using the JCL in ADCD.LIB.JCL(SMFGDG). The procedures SMFCLEAR and SMFDUMPS are available in ADCD.Z22B.PROCLIB.

## Using the esoteric devices

Esoteric devices that are called WORK, TEMP, and SORT have been defined and mapped to devices in the range 0600 – 060F. To use these esoterics, create emulated 3390 volumes in your zPDT system and map them to these device addresses by using the devmap file.

Update the appropriate VATLSTxx member (volume attribute list) as shown in this example. This example uses volumes WORK01 through WORK12, which are marked as WORK\*. This member defines the mount and use attributes of direct-access volumes.

```
VATDEF IPLUSE(PRIVATE),SYSUSE(PRIVATE)
B2SYS1,0,0,3390 ,Y
WORK* ,0,0,3390 ,Y
```

## Starting IBM Health Checker for z/OS

With this edition, IBM Health Checker is preconfigured to start automatically.

To start this utility manually, use this start command.

```
/START HZSPROC
```

To stop IBM Health Checker, enter this command manually, or include it in your shutdown script SHUTxx in parmlib.

```
/STOP HZSPROC
```

### Related information:

 [IBM Health Checker for z/OS](#)

## Starting IBM z/OS Management Facility (z/OSMF)

A new load parm (IZ) is configured to start the z/OSMF product. These commands are listed here for reference. However, they are included in the startup script member VTAMCI/DB/IM/IZ/WA/AL so that z/OSMF starts automatically. The first command starts the CIM (Common Information Model) server, and the second command starts z/OSMF. The CIM server needs to be started before you start the z/OSMF product. The WebSphere Application Server OEM provides a native application server runtime environment for z/OSMF.

```
S CFZCIM
```

It might take several minutes for these applications to start. Look for these messages for successful start of the z/OSMF product.

```

S IZUANG1
CWWKB0056I INITIALIZATION COMPLETE FOR ANGEL
S IZUSVR1
IZUG400I: The z/OSMF Web application services are initialized.
+CWWKF0011I: The server zosmfServer is ready to run a smarter planet.

```

To access the z/OSMF console, open a browser on the Welcome page URL:  
<https://hostname:port/zosmf/>

*hostname*

The host name or IP address of the system in which z/OSMF is installed.

*port*

The secure application port for the z/OSMF configuration. The port is optional. If you specified a secure port for SSL encrypted traffic during the configuration process (through parmlib statement HTTP\_SSL\_PORT), that value is required to log in. Otherwise, it is assumed that you are using port 443, the default.

To stop z/OSMF, enter these commands:

```

P IZUSVR1
P CFZCIM
P IZUANG1
18

```

## Starting WebSphere Application Server (WAS V8)

Learn how to start WebSphere Application Server v8.

You must have more than 4 GB real memory on your system and allocate at least 3000 m (3 GB) in the devmap. IPL the system with loadparm WA and follow these steps to start WebSphere Application Server V8:

1. In SDSF, type / and press Enter to open the System Command Extension window.
2. To start the Deployment Manager, type this command in the System Command Extension window and press Enter: START XEDCR,JOBNAM=XEDMGR,ENV=XECCELL.XEDMNODE.XEDMGR.

```

System Command Extension

Type or complete typing a system command, then press Enter.

==> START XEDCR,JOBNAM=XEDMGR,ENV=XECCELL.XEDMNODE.XEDMGR
==>

Place the cursor on a command and press Enter to retrieve it.
More: +

=> D U,,,1880,19
=> D U,,,1880,32
=> D U,,,6C8,1
=> V 1890-1892,ONLINE
=> V 188D-188F,ONLINE
=> D U,VOL=VPADCD
=> R 6,U

_ Wait 1 second to display responses (specify with SET DELAY)
_ Do not save commands for the next SDSF session

F1=Help F5=FullScr F7=Backward F8=Forward F11=ClearLst F12=Cancel

```

The start command might take several minutes to complete. When it is complete, this message is written to the system log: BB000019I INITIALIZATION COMPLETE FOR WEBSphere FOR Z/OS CONTROL 478 PROCESS XEDMGR.

3. Issue this command to start the Node Agent: START XEACR1,JOBNAME=XEAGNT1,ENV=XECELL.XENODE1.XEAGNT1.

This command might take several minutes to complete. When it is complete, this message is written to the system log: BB000019I INITIALIZATION COMPLETE FOR WEBSphere FOR Z/OS CONTROL 346 PROCESS XEAGNT1.

4. To connect to the Admin console, open a browser on this URL: `http://hostname:port/ibm/console`.


A login window with the user ID **xadmin** opens.




5. Click **Log in**.

The Admin console opens.

6. To start the Application Server from the Admin console:
  - a. In the navigation list, click **Servers > Server Types > Websphere application servers**.
  - b. In the Application servers view, select the check box beside server **XESR011**.
  - c. Click **Start**.



This operation might take several minutes to complete. When it is complete, this message is written in the system log: BB000019I INITIALIZATION COMPLETE FOR WEBSphere FOR Z/OS CONTROL 541 PROCESS XESR011. When the server is started, the **Status** column displays a green arrow:



7. To start a sample application for installation verification, open a browser on this URL: `http://hostname:port/snoop`.  
A page like this one opens, indicating successful start of the sample application Snoop:

## Snoop Servlet - Request/Client Information

### Requested URL:

`http://s0w1.dal-ebis.ihost.com:9667/snoop`

### Servlet Name:

Snoop Servlet

### Request Information:

|                    |          |
|--------------------|----------|
| Request method     | GET      |
| Request URI        | /snoop   |
| Request protocol   | HTTP/1.1 |
| Servlet path       | /snoop   |
| Path info          | <none>   |
| Path translated    | <none>   |
| Character encoding | <none>   |
| Query string       | <none>   |

To stop the application server, do one of these actions:

- From the browser:
  1. Selecting the server and then click **Stop**.
  2. On the confirmation window, click **OK**.
- From SDSF, issue this command: `/P XESR011`.

When the application server is shut down, this message is written to the system log: `BB000002I WEBSPPHERE FOR Z/OS CONTROL PROCESS XESR011 ENDED NORMALLY.`

To stop the Deployment Manager and Node Agent, issue this command: `/P XEDEMN`.

| Display                    | Filter     | View     | Print    | Options         | Search       | Help                     |
|----------------------------|------------|----------|----------|-----------------|--------------|--------------------------|
| -----                      |            |          |          |                 |              |                          |
| SDSF DA ADCD               | ADCD113S   | PAG 0    | CPU/L    | 11/**           | LINE 1-4 (4) |                          |
| COMMAND INPUT ==> /P XEDEM |            |          |          | SCROLL ==> PAGE |              |                          |
| PREFIX=XE*                 | DEST=(ALL) | OWNER=*  | SYSNAME= |                 |              |                          |
| NP                         | JOBNAME    | StepName | ProcStep | JobID           | Owner        | C Pos DP Real Paging SIO |
|                            | XEDEM      | XEDEM    | BBODAEMN | STC00036        | XEACRU       | NS FE 297 0.00 0.00      |
|                            | XEDMGR     | XEDMGR   | BBOPDCR  | STC00033        | XEACRU       | NS FE 36T 0.00 0.00      |
|                            | XEAGNT1    | XEAGNT1  | BBOPACR  | STC00038        | XEACRU       | NS FE 34T 0.00 0.00      |
|                            | XEDMGRS    | XEDMGRS  | BBOPDSR  | STC00037        | XEASRU       | IN F6 125T 0.00 0.00     |

The stop command might take several minutes to complete. When it is complete, this message is written to the system log: BB000008I WEBSPHERE FOR Z/OS DAEMON S0W1 ENDED NORMALLY.

## Starting WebSphere Application Server (WAS V8.5)

Learn how to start WebSphere Application Server v8.5.

You must have more than 4 GB real memory on your system and allocate at least 3000 m (3 GB) in the devmap. IPL the system with loadparm WA and follow these steps to start WebSphere Application Server V8.5:

1. In SDSF, type / and press Enter to open the System Command Extension window.
2. To start the Deployment Manager, type this command in the System Command Extension window and press Enter: START XFDCR,JOBNAME=XFDMGR,ENV=XFCELL.XFDMNODE.XFDMGR.

```

System Command Extension

Type or complete typing a system command, then press Enter.

==> START XFDCR,JOBNAME=XFDMGR,ENV=XFCELL.XFDMNODE.XFDMGR
==>

Place the cursor on a command and press Enter to retrieve it.
More: +

=> P IMS11RL1
=> 05,/CHE FREEZE
=> 04,/CHE SNAPQ
=> 03,/DIS LTERM ALL
=> 02,/NRE CHKPT 0 FORMAT ALL
=> P IMS12RL1
=> -DBAG STO DB2

_ Wait 1 second to display responses (specify with SET DELAY)
_ Do not save commands for the next SDSF session

F1=Help F5=FullScr F7=Backward F8=Forward F11=ClearLst F12=Cancel

```

The start command might take several minutes to complete. When it is complete, this message is written to the system log: BB000019I INITIALIZATION COMPLETE FOR WEBSPHERE FOR Z/OS CONTROL 478 PROCESS XFDMGR.

3. Issue this command to start the Node Agent: START XFACR1,JOBNAME=XFAGNT1,ENV=XFCELL.XFNODE1.XFAGNT1.


This command might take several minutes to complete. When it is complete, this message is written to the system log: BB000019I INITIALIZATION COMPLETE FOR WEBSPHERE FOR Z/OS CONTROL 346 PROCESS XFAGNT1.

4. To connect to the Admin console, open a browser on this URL:  
`http://hostname:port/ibm/console`.


A login window with the user ID **xfadmin** opens.



5. Click **Log in**.  
The Admin console opens.
6. To start the Application Server from the Admin console:
  - a. In the navigation list, click **Servers > Server Types > Websphere application servers**.
  - b. In the Application servers view, select the check box beside server **XFSR011**.
  - c. Click **Start**.



This operation might take several minutes to complete. When it is complete, this message is written in the system log: BB000019I INITIALIZATION COMPLETE FOR WEBSPPHERE FOR Z/OS CONTROL 541 PROCESS XFSR011. When the server is started, the **Status** column displays a green arrow:



7. To start a sample application for installation verification, open a browser on this URL: `http://hostname:port/snoop`.

A page like this one opens, indicating successful start of the sample application Snoop:

## Snoop Servlet - Request/Client Information

### Requested URL:

`http://s0w1.dal-ebis.ihost.com:9767/snoop`

### Servlet Name:

Snoop Servlet

### Request Information:

|                    |          |
|--------------------|----------|
| Request method     | GET      |
| Request URI        | /snoop   |
| Request protocol   | HTTP/1.1 |
| Servlet path       | /snoop   |
| Path info          | <none>   |
| Path translated    | <none>   |
| Character encoding | <none>   |
| Query string       | <none>   |

To stop the application server, do one of these actions:

- From the browser:
  1. Selecting the server and then click **Stop**.
  2. On the confirmation window, click **OK**.
- From SDSF, issue this command: `/P XFSR011`.

When the application server is shut down, this message is written to the system log: `BB000002I WEBSPPHERE FOR Z/OS CONTROL PROCESS XFSR011 ENDED NORMALLY.`

To stop the Deployment Manager and Node Agent, issue this command: `/P XFDEMN`.

The stop command might take several minutes to complete. When it is complete, this message is written to the system log: `BB000008I WEBSPPHERE FOR Z/OS DAEMON S0W1 ENDED NORMALLY.`





---

## Index

### Special characters

/tmp and /u, create new zFS files for 8

### A

ADCD.Z111S.PROCLIB 7

### C

Configuration overview 8  
configuring a working z/OS system 6

### E

emulators not native to the Linux 17  
environment, starting z Systems  
Development and Test Environment 4

### I

IEASYSxx 7  
IPL process 7

### J

JES NJE connectivity, defining 19

### L

Linux routing, setting up 12  
LOADxx 7

log on, z/OS 8  
logon procedure, defining a new 18  
Logon to TSO 17

### M

MSTJCLxx 7

### N

new logon procedure, defining 18  
non-native Linux emulators 17

### O

optional tasks 17

### P

PROFILE.TCPIP, modifying 13

### R

routing, Linux, setting up 12

### S

starting z Systems Development and Test  
Environment environment 4  
SYS1.PROCLIB 7  
system configuration, introduction 6

system procedure library 7  
system shutdown script, altering 18  
system startup script, altering 18

### T

TCP/IP, setting up 11  
TCPIP.DATA, modifying 14  
TCPPARMS files, modifying 13  
TSO logon 17  
TSO user IDs, creating new 17

### U

USER.PROCLIB 7  
USER.TCPPARMS, modify TCP/IP  
procedures to point to 15

### W

working z/OS system, configuring 6

### Z

z Systems Development and Test  
Environment environment, starting 4  
z/OS system configuration, introduction  
to 6  
z/OS, logging on 8  
zFS file creation, /tmp and /u 8